

## LIST OF PRODUCTS

- \* Digital Multimeter
- \* Digital AC & AC/DC Clampmeter
- \* AC Clamp Adaptor
- \* AC/DC Current Adaptor
- \* Transistorised Electronic Analog & Digital Insulation Resistance Testers(upto 10 KV)
- \* Digital Sound Level Meter & Sound Level Calibrator
- \* Digital contact & Non-contact Type Tachometer
- \* Digital Non-contact (infrared) Thermometer
- \* Thermo Hygrometer
- \* Thermo Anemometer
- \* Wood & Paper Moisture Meter
- \* Distance Meter
- \* Digital Hand Held Temperature Indicators
- \* Digital Lux Meter
- \* Network Cable Tester
- \* Power Factor Regulator
- \* Maximum Demand Controller/Digital Power Meter
- \* Earth Resistance Tester

**KUSAM-MECO**

17, Bharat Industrial Estate, T. J. Road, Sewree (W),  
Mumbai-400015. INDIA

Sales Direct: 24156638 Tel.:(022)2412 4540, 2418 1649 Fax:2414 9659

E-mail : kusam\_meco@vsnl.net, Website : www.kusamelectrical.com,  
www.kusam-meco.co.in

**KUSAM-MECO**

An ISO 9001:2008 Company

**DIGITAL  
MULTIMETER  
KM 6030**

**OPERATION  
MANUAL**

**KUSAM-MECO**

**OPERATION MANUAL  
DIGITAL  
MULTIMETER  
KM 6030**



**KUSAM-MECO**

**TAKE MEASUREMENT CAREFULLY AND YOU'LL  
SPARE YOUR METER AND YOURSELF, SOME PAIN**

Nearly every electrical engineer has a hand held Multimeter. We sometimes take them for granted, until we damage them or "burn them out" if you incorrectly connect your DMM to a circuit or have the DMM on wrong setting, you damage the meter and possibly hurt yourself. You can also get into trouble if you try to measure the voltage across a charged capacitor.

DMM users frequently burn their meters by trying to measure current the same way as they measure voltage, Remember, you measure voltage across a circuit, and current through a circuit. When you use the current input, your DMM becomes a lower impedance circuit element. If you accidentally connect this low impedance path across your circuit, you'll effectively short-circuit it. You can, therefore send high current through your meter and severely damage it. Unless the meter has a fused input, you can even get an explosion or fire.

Even if you correctly insert your DMM into the circuit, you can still damage your meter. Don't try to measure current in excess of your meter's capacity. Handheld DMMs usually have a maximum current rating of 10A or 20A.

If you are measuring current in industrial environment, you can easily exceed those ratings. The best way to avoid damage is to use a clamp meter or to connect a clamp attachment to your DMM.

To prevent excess current from flowing through your meter, always disconnect the test leads from the circuit under test whenever you change DMM functions, Set your meter to the correct function, say current and its highest range for the setting, say 20A. Next, connect the test leads before you apply power to the circuit. To be safe, start by setting your meter to its highest range first.

**Table of Contents**

Title	Page
<b>Overview</b> .....	1
<b>Unpacking Inspection</b> .....	1
<b>Features</b> .....	2
<b>General Specifications</b> .....	3
<b>Electrical Specifications</b> .....	4
<b>A.</b> DC Voltage	
<b>B.</b> AC Voltage	
<b>C.</b> AC Current	
<b>D.</b> DC Current	
<b>E.</b> Resistance	
<b>F.</b> Capacitance	
<b>G.</b> Temperature	
<b>H.</b> Frequency	
<b>I.</b> Transistor hFE Test	
<b>J.</b> Diode Test & Continuity	
<b>Rules For Safe Operation</b> .....	7
<b>International Electrical Symbols</b> .....	8
<b>The Multimeter Structure</b> .....	9
<b>Functional Buttons</b> .....	10
<b>Display Symbols</b> .....	11
<b>Measurement Operation</b>	
<b>A.</b> DC Voltage .....	12
<b>B.</b> AC Voltage .....	13
<b>C.</b> AC Current.....	15
<b>D.</b> DC Current.....	16
<b>E.</b> Resistance.....	18
<b>F.</b> Capacitance.....	20
<b>G.</b> Temperature.....	21
<b>H.</b> Frequency.....	22
<b>I.</b> Diode Test & Continuity.....	23
<b>J.</b> Transistor hFE Test.....	25
<b>Maintenance</b> .....	26
<b>A.</b> Replacing the Battery	
<b>Test Certificate</b> .....	27
<b>Warranty</b> .....	28

**OVERVIEW**

**⚠ Warning**

**To avoid electric shock or personal injury, read the “Safety Information” and “Rules for Safe Operation” carefully before using the Meter.**

Digital Multimeter Model - 6030 (hereafter referred to as “the Meter”) is a 3½ digits Multimeter with steady operations, and highly reliable hand-held measuring instrument having different measurement positions. The Multimeter not only can measure AC/DC Voltage, AC/DC Current, Resistance, Capacitance, Frequency, Temperature, Transistor hFE Test, Diode Test, but also has Data Hold, Range & function selection & backlight display.

**Terms in this manual**

**⚠ Warning :** Identifies conditions and actions that could result in serious injury or even death to the user.

**⚡ Caution :** Identifies conditions and actions that could cause damage or Malfunction in the instrument.

**Unpacking Inspection**

Open the package case and take out the Multimeter. Check the following items carefully to see any missing or damaged part :


Item	Description	Qty.
1	English Operating Manual	1 piece
2	Test Lead	1 pair
3	Temperature Probe	1 piece

In the event you find any part missing or damaged, please contact your dealer immediately.

**FEATURES :**

- **Low power consumption CMOS double integration, A/D transform integrated circuit, Auto Zero Calibration, Auto Polarity display, Data Hold, Low Battery & Over range indication.**
- **Display :** 3½ digit (2000 Counts) with digit height 28mm and function/units sign annunciators.
- **Selected Range displayed on LCD.**
- **Test lead jack mechanical protection function & full Range over-load protection function.**
- **Polarity :** Automatic (-) negative polarity indication.
- **Auto Power Off :** The meter will shut off automatically about 15 minutes after power is ON if the meter is not in use.
- **High Accuracy - Digital Reading.**
- **Instant Continuity Buzzer.**
- **Overload Protection in all Ranges.**
- **Recessed Safety Designed Input Jacks.**
- **“DATA - HOLD ” switch freezes reading.**
- **Back light display .**
- **Range & Function Selection.**

**GENERAL SPECIFICATIONS :**

- Display** : 3½ digit LCD. Maximum reading 2000 with automatic sign and Function annunciators.
- Digital Size** : 28mm(H)
- Overrange indication** : Highest digit of (1) or (-1) is displayed.
- Low battery** : The “” sign is Displayed when the battery Voltage drops below the operating Voltage.
- Measurement rate** : 2.5 measurements per Second, nominal.
- Operating temperature** : 0°C to + 50°C, <70% RH.
- Storage temperature** : -20°C to 60°C, <80% RH with battery removed.
- Accuracy** : Accuracy specifications at 23 ± 5°C less than 75% RH.
- Power** : Single 9 V Battery.
- Dimension** : 192mm (L), 88mm(W), 42mm(H)
- Weight** : Approx (600 grams) including battery
- Accessories** : Test leads, Operators Manual, Battery, Carrying Case, Protective Holster, Temp. Probe.

## ELECTRICAL SPECIFICATION :

### DC VOLTAGE

Range	Resolution	Accuracy
200 mV	100 V	±(0.5% rdg + 3dgts)
2 V	1 mV	
20 V	10 mV	
200 V	100 mV	
1000 V	1 V	

**Input Impedance :** 10M

**Overload Protection :** 250V(for 200mV),DC or AC

Peak value, 1000V( for other range)

### AC VOLTAGE

Range	Resolution	Accuracy
2 V	1 mV	±(0.8% rdg +3 dgts)
20 V	10 mV	
200 V	100 mV	
700 V	1 V	

**Input Impedance :** 10M

**Frequency range :** 40Hz~ 400Hz(it is 40Hz-100Hz in 200V, 750V range position)

**Overload Protection :** 250V(for 200mV),DC or AC peak value,1000V on all other ranges.

### AC CURRENT (40Hz~400Hz)

Range	Resolution	Accuracy
2 mA	1 A	±(1.0% rdg +3dgts)
20 mA	10 A	
200 mA	100 A	
20 A	10 mA	

**Overload Protection:** 0.2A/250 V fuse

**Max input current :** 20A

## DC CURRENT

Range	Resolution	Accuracy
2 mA	1 A	±(0.8% rdg +2dgts)
20 mA	10 A	
200 mA	100 A	
20 A	10 mA	

**Overload Protection:** 0.2A/250 V fuse

**Max input current :** 20A

## RESISTANCE

Range	Resolution	Accuracy
200	0.1	±(0.8% rdg +3 dgts)
2 K	1	
20 K	10	
200K	100	
2 M	1 K	±(1.0% rdg + 5 dgts)
20 M	10 K	

**Overload Protection :** 250V DC or AC peak value.

Open circuit voltage: <1V.

## CAPACITANCE

Range	Resolution	Accuracy
2 F	1 pF	±(0.8% rdg + 3 dgts)
20 F	10 pF	
200 F	100 pF	
2 F	1 F	±(3.0% rdg + 3 dgts)
200 F	100 F	

**Frequency Measurement:** Approx.400Hz

**Voltage Measurement :** Approx. 40mV

**TEMPERATURE**

Range	Resolution	Accuracy
-40°C~400°C	1°C	±(0.75% rdg + 4dgts)
400°C~1000°C		±(1.5%rdg + 15dgts)

**FREQUENCY**

Range	Resolution	Accuracy
2 KHz	1 Hz	±(2.0% rdg + 5dgts)

**Overload Protection** : 500 V DC or AC peak value.

**Input Sensitivity** : 150 mV rms

**TRANSISTOR hFE MEASUREMENT**

Range	Description	
hFE	It can measure NPN or PNP type of transistor triode hFE parameter. Indication range : 0~1000	1b approx. 10uA, Vec approx. 2.8 V

**DIODE AND CONTINUITY MEASUREMENT**

Description	
Indicate approx forward-way voltage drop of diode	Forward-way current is approx. 1mA conray-way voltage is approx. 2.8 V. Open circuit voltage is approx. 2.8V.
The buzzer inside sounds when continuity resistance is about <50	

**Overload Protection** : 250 V AC or DC peak value.

**Rules For Safe Operation (1)**




**Warning**












**To avoid possible electric shock or personal injury, and to avoid possible damage to the Meter or to the equipment under test, adhere to the following rules :**

- ✦ Before using the Meter inspect the case. Do not use the Meter if it is damaged or the case (or part of the case) is removed. Look for cracks or missing plastic. Pay attention to the insulation around the connectors.
- ✦ Inspect the test leads for damaged insulation or exposed metal. Check the test leads for Continuity. Replace damaged test leads with identical electrical Specifications before using the Meter.
- ✦ Do not apply more than the rated voltage, as marked on the Meter, between the terminals or between any terminal and grounding.
- ✦ The rotary switch should be placed in the right position and no any changeover of range shall be made while measurement is conducted to prevent damage of the Meter.
- ✦ When measurement is taken at an effective voltage over 60V in DC or 30V rms in AC, special care should be taken for there is danger of electric shock.
- ✦ Use the proper terminals, function, and range for your measurements.
- ✦ Do not use or store the Meter in an environment of high temperature, humidity, explosive, inflammable and strong magnetic field. The performance of the Meter may deteriorate after the meter is dampened.
- ✦ When using the test leads, keep your fingers behind the finger guards.


## Rules For Safe Operation (2)

- ✎ Disconnect circuit power and discharge all high-voltage capacitors before testing resistance, continuity, diodes, current or capacitance.
- ✎ Replace the battery as soon as the battery indicator  appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- ✎ Turn the Meter power off when it is not in use and take out the battery when not using for a long time.
- ✎ Constantly check the battery as it may leak when it has not been used for some time, replace the battery as soon as leaking appears. A leaking battery will damage the Meter.

## International Electrical Symbols

	AC (Alternating Current).
	DC (Direct Current).
	Both DC & AC.
	Grounding.
	Double Insulated.
	Deficiency of Built-In Battery.
	Continuity Test.
	Diode.
	Fuse.
	Warning ! Refer to the Operating Manual.
	Caution ! Risk of Electric Shock.

## The Multimeter Structure (see figure 1)



( Figure 1)

- 1) **LCD DISPLAY :**  
A 3½ digit display (maximum reading 1999) indicates measured values, and features symbols indicating function, Low Battery, Continuity, Diode.
- 2) **FUNCTION SELECTOR :**  
To Select ACV, DCV, ACA, DCA, Resistance, Capacitance, Temperature, Frequency, Diode, Continuity & Transistor Test.
- 3) **INPUT JACKS (V m and COM) :**  
Test leads are inserted into these jacks for Voltage, Resistance, Current measurements, Continuity & Diode Checks.
- 4) **POWER SWITCH :**  
A push button (ON/OFF) POWER switch will switch ON or switch OFF the multimeter.
- 5) **DATA HOLD SWITCH :**  
A push button ( ON/OFF) Data-Hold switch will freeze reading when pressed.

**6) BACK LIGHT SWITCH:**

To turn OFF or ON the back light so that readings Can be taken in the dark.

**7) FUNCTION SELECTOR:**

To select various functions

**8) INPUT SOCKET FOR TEMPERATURE MEASUREMENT :**

Temperature Probes are inserted into these jacks and the other end is connected to the point where the temperature is to be measured.

**9) INPUT SOCKET FOR CAPACITANCE MEASUREMENT :**


Capacitors are inserted into these jacks whose capacitance is to be measured.

**10) INPUT SOCKET FOR TRANSISTOR TEST.**

**11) PROTECTIVE HOLSTER :**

Prevents the instrument from damage. the hand while in use.

**Display Symbols** (see figure 2)





**( Figure 2)**


No.	Symbol	Meaning
1		Dangerous Voltages.
2		The battery is low. ⚠ Warning : To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.
3		Indicator for AC voltage or current, The displayed value is the mean value.
4		Indicates negative reading.
5		Test of diode.
6		Data Hold is active.
7		The continuity buzzer is on.
8	<b>mA, A</b>	A : Amperes (amps). The unit of current.
9	<b>mV, V</b>	V : Volts. The unit of voltage.
10	<b>Hz</b>	Hz : The unit of frequency.
11	, k ,	: Ohm. The unit of resistance. K : kilohm. $1 \times 10^3$ or 1000 ohms.
12	°C	°C : The unit of temperature.
13	F, F	The unit of capacitance.



## MEASUREMENT OPERATION

- Make sure the Low Battery display  is not on, otherwise false readings may be provided.
- Pay extra attention to the  symbol which is located besides the input terminals of the Meter before carrying out measurement.

### A. DC voltage measurement (see figure 3)




( Figure 3 )



**Warning**  
To avoid harms to you or damages to the Meter from electric shock, please do not attempt to measure voltages higher than 1000VDC or 700V rms although readings may be obtained.


The DC Voltage ranges are :200mV, 2V, 20V, 200V, 1000V.  
To measure DC voltage, connect the Meter as follows :

- 1) Insert the red test lead into the **V** input terminal and the black test lead into the **COM** input terminal
- 2) Set the rotary switch to an appropriate measurement position in **V**  range.
- 3) Connect the test leads across with the object being measured.  
The measured value is shown on the display.

### Caution :

- If the value of voltage to be measured is unknown, use the maximum measurement position (1000V) and reduce the range step by step until a satisfactory reading is obtained.
- The LCD displays "1" indicating the existing selected range is overloaded, it is required to select a higher range in order to obtain a correct reading.
- In each range, the Meter has an input impedance of approx. 10M . This loading effect can cause measurement errors in high impedance circuits. If the circuit impedance is less than or equal to 10k , the error is negligible (0.1% or less).
- When DC voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

### B. AC Voltage Measurement (see figure 4)



( figure 4 )

**⚠ Warning :**

**To avoid harm to you or damages to the Meter from electric shock, please do not attempt to measure voltages higher than 1000V or 700V rms although readings may be obtained.**

The AC Voltage measurement has 4 measurement positions on the rotary switch : 2V, 20V, 200V and 700V


**To measure AC Voltage, connect the Meter as follows :**

- 1) Insert the red test lead into the V terminal and the black test lead into the **COM** terminal.
- 2) Set the rotary switch to an appropriate measurement position in V ~ range.
- 3) Connect the test leads across with the object being measured.  
The measured value is shown on the display, which is effective value of sine wave (mean value response).

**⚡ Caution :**

- If the value of voltage to be measured is unknown, use the maximum measurement position (700V) and reduce the range step by step until a satisfactory reading is obtained.
- The LCD displays " 1 " indicating the existing selected range is overloaded, it is required to select a higher range in order to obtain a correct reading.
- When AC Voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

- When AC Voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

**C. AC Current Measurement** (see figure 5)**⚠ Warning :** (figure 5)

Never attempt an in - circuit current measurement where the open circuit voltage between terminals and ground is greater than 60V DC or 30V rms. If the fuse burns out during measurement, the Meter may be damaged or the operator himself may be hurt. Use proper terminals, function, and range for the measurement. When the testing leads are connected to the current terminals, do not parallel them across any circuit.

The AC current measurement has 4 measurement positions on the rotary switch : 2mA, 20mA, 200mA, 20A.


**To measure AC Current, connect the meter as follows :**

- 1) Turn off power to the circuit. Discharge all High - Voltage capacitors.
- 2) Insert the red test lead into the mA or 20A terminal and the black test lead into the **COM** terminal
- 3) Set the rotary switch to an appropriate measurement position in Current range.
- 4) Break the current path to be tested. Connect the red test lead to the positive side of the path and the black test lead to the negative side of the path.
- 5) Turn on power to the circuit.  
The measured value is shown on the display.

**⚠ Caution**

- If the value of current to be measured is unknown, use the maximum measurement position (20A) and 20A terminal, and reduce the range step by step until a satisfactory reading is obtained.
- When current measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

**D. DC Current Measurement** (see figure 6)



(figure 6)

**⚠ Warning :**

Never attempt an in - circuit current measurement where the open circuit voltage between terminals and ground is greater than 60V DC or 30V rms. If the fuse burns out during measurement, the Meter may be damaged or the operator himself may be hurt. Use proper terminals, function, and range for the measurement. When the testing leads are connected to the current terminals, do not parallel them across any circuit.

The DC current measurement has 4 measurement positions on the rotary switch : 2mA, 20mA, 200mA, 20A.

**To measure DC Current, connect the meter as follows :**

- 1) Turn off power to the circuit. Discharge all High - Voltage capacitors.
- 2) Insert the red test lead into the mA or 20A terminal and the black test lead into the **COM** terminal
- 3) Set the rotary switch to an appropriate measurement position in Current range.
- 4) Break the current path to be tested. Connect the red test lead to the positive side of the path and the black test lead to the negative side of the path.
- 5) Turn on power to the circuit.

The measured value is shown on the display.


**⚠ Caution**

- If the value of current to be measured is unknown, use the maximum measurement position (20A) and 20A terminal, and reduce the range step by step until a satisfactory reading is obtained.
- When current measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

**E. Resistance Measurement** (see figure 7)

**⚠ Warning**

**To avoid damages to the Meter or to the devices under test, disconnect circuit power and discharge all the high-voltage capacitors before measuring resistance.**



**(figure 7)**

The resistance range has 6 measurement positions on the rotary switch : 200

**To measure resistance, connect the meter as follows**

- 1) Insert the red test lead into the V terminal and the black test lead into the COM terminal.
- 2) Set the rotary switch to an appropriate measurement position in range.
- 3) Connect the test leads across with the resistance being measured.  
The measured value is shown on the display.

**Note :**

- The test leads can add 0.1 to 0.3 of error to the Resistance measurement. To obtain precision readings in low-resistance, that is the range of 200 , short-circuit the input terminals beforehand and record the reading obtained (call this reading as X). (X) is the additional resistance from the test Lead. Then use the equation :  
Measured resistance value (Y) - (X) = precision Reading of resistance.
- When there is no input, for example in open circuit condition, the Meter displays " 1"  
When resistance measurement has been completed, disconnect the connection between the testing leads and the circuit under test.


**⚠ Caution :**

- 1) Never connect high voltage to the input sockets with the switch in Resistance range.
- 2) Using Resistance measurement function in a Live circuit will produce false results and may damage the instrument. In many cases the suspect component must be disconnected from the circuit to obtain an accurate reading.

## F. Capacitance Measurement (see figure 8)

### Warning

To avoid damages to the Meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the DC voltage function to confirm that the capacitor is discharged. Never attempt to input over 60V in DC or 30V rms in AC to avoid personal injury.



(figure 8)

Capacitance measurement has 5 measurement positions on the rotary switch : 2nF, 20nF, 200nF, 2 F and 200 F.


To measure capacitance, connect the Meter as follows

- 1) Set the function/range switch on the range position needed.

### Caution :

- 1) Never connect high voltage to the input Sockets with the switch in Capacitance range.
- 2) Using Capacitance measurement function in a Live circuit will produce false results and may damage the instrument. In many cases the suspect component must be disconnected from the circuit to obtain an accurate reading.

## G. TEMPERATURE MEASUREMENT (see figure 9)



(figure 9)

Temperature measurement range is from - 40°C to 1000°C.

To measure temperature, connect the Meter as follows:


- 1) Set the function switch on the "C" measurement position.
- 2) Insert the thermocouple plug into the meter's temperature socket.
- 3) The temp. probe supplied along with the instrument can measure temp. Upto 250°C. To measure temp. above 250°C please request for higher temp. measurement probe.

- 3) Insert the plug with the positive polarity in the positive socket and the negative polarity in the negative socket.
- 4) Set the measurement end of the thermocouple on the temperature measurement point. The measured value is shown on the display.

#### H. Frequency Measurement (see figure 10)

##### **Warning :**

To avoid harm to you or damages to the Meter, do not attempt to measure voltages higher than 60V in DC or 30V rms in AC although reading may be obtained. When the frequency signal to be tested is higher than 30V rms, the Meter cannot guarantee accuracy of the measurement.



(figure 10)

The frequency measurement range is 2kHz.  
To measure frequency, connect the Meter as follows :

- 1) Insert the red test lead into the **V** terminal and the black test lead into the **COM** Terminal.
- 2) Set the rotary switch in the 2kHz range.
- 3) Connect the test leads across with the object being measured.

The measured value is shown on the display.

##### **Caution :**

- When Hz measurement has been completed, disconnect the connection between the testing leads and the circuit under test.

#### I. Measuring Diodes & Continuity (See figure 11)

##### **Warning**


To avoid damage to the Meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring diodes and continuity.

##### **Testing Diodes**

Use the diode test function to check diodes, The diode test sends a current through the Semiconductor junction, and then measures the voltage drop across the junction. A good silicon junction drops between 0.5V and 0.8V.




**MAINTENANCE****△ Warning**

To avoid false reading, replace the battery as soon as the battery indicator  appears.

**To replace battery :**

- Disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.
- Turn the Meter OFF.
- Remove the screws from the battery compartment, and separate the battery compartment from the case bottom
- Remove the battery from the battery compartment.
- Replace the battery with a new Standard 9V Battery.
- Rejoin the battery compartment and the case bottom, and install the screw.

**MUMBAI****TEST CERTIFICATE****DIGITAL MULTIMETER**

This Test Certificate warrants that the product has been inspected and tested in accordance with the published specifications.

The instrument has been calibrated by using equipment which has already been calibrated to standards traceable to national standards.

MODEL NO. **KM 6030**

SERIAL NO. \_\_\_\_\_

DATE: \_\_\_\_\_

**ISO 9001  
REGISTERED**



**KUSAM-MECO**

## **WARRANTY**

Each "KUSAM-MECO" product is warranted to be free from defects in material and workmanship under normal use & service. The warranty period is one year (12 months) and begins from the date of despatch of goods. In case any defect occurs in functioning of the instrument, under proper use, within the warranty period, the same will be rectified by us free of charges, provided the to and fro freight charges are borne by you.

This warranty extends only to the original buyer or end-user customer of a "KUSAM-MECO" authorized dealer.

This warranty does not apply for damaged Ic's, fuses, burnt PCB's, disposable batteries, carrying case, test leads, or to any product which in "KUSAM-MECO's" opinion, has been misused, altered, neglected, contaminated or damaged by accident or abnormal conditions of operation or handling.

"KUSAM-MECO" authorized dealer shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of "KUSAM-MECO".

"KUSAM-MECO's" warranty obligation is limited, at option, free of charge repair, or replacement of a defective product which is returned to a "KUSAM-MECO" authorized service center within the warranty period.

**KUSAM-MECO**

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. "KUSAM-MECO" SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE WHATSOEVER.

All transactions are subject to Mumbai Jurisdiction.

**KUSAM-MECO**

G 17, Bharat Industrial Estate, T. J. Road,  
Sewree (W), Mumbai - 400 015. INDIA.

**Sales Direct :** (022) 24156638

**Tel. :** (022) 24124540, 24181649.

**Fax :** (022) 24149659

**Email :** kusam\_meco@vsnl.net

**Website :** www.kusamelectrical.com

www.kusam-meco.co.in