

Model - KM 2805 MK-1 insulation resistance tester is a handheld instrument designed primarily to make resistance / insulation resistance measurement

Model KM 2805 MK-1



Preliminary Data

PHYSICAL SPECIFICATION

Display (LCD)	Digital : 9999 Counts, Analog bar graph with LCD backlight
Operating Temperature	-10°C~40°C (14°F~104°F)
Storage Temperature	-20°C~ 60°C (-4°F~ 152°F)
Relative Humidity	≤ 85% @ 0°C~ 40°C below ; ≤ 90% @ -20°C ~ 60°C.
Battery Type	8 pcs of 1.5V (LR 14) Batteries or power adaptor (input voltage 230, 50/60Hz, 150 mA, input DC15V, 1.0A). (optionally available at extra cost.)
Dimensions	202(H) x 155(W) x 94(L) mm
Weight	Approx. 2kg (including battery).

GENERAL SPECIFICATION

Range	Auto ranging.
Overloading	Display OL on Insulation Resistance range
Battery Indicator	Displays Battery Condition
Icon Display	Equips with function and battery indicator icons.
Current Consumption	Maximum : around 1.0A, Average : around 20mA
Display Backlight	Bright backlight for clear readings in poorly lighted areas.
Computer Connection	Via USB interface.
Data Logging and Recall	18 points
Autorange	The Meter automatically selects best range
Warning	⚠ And red light will on.
Voltage	Auto discharge Voltage function
Compare Measurement	Use the compare function to set a pass/fail compare level for the insulation measurements.
PI Measurement	Polarization Index is the ratio of insulation resistance. You can pre-set two points of time and automatically carry out the measurement
Time	To carry out measurement by setting specified time within 15 Minutes
Accessories	Two pcs of plug test lead to one alligator clip (Black & Green), One pc of Two plugs test lead to alligator clip (Red), Batteries, User's manual, Tool Box, USB interface cable, Software, Power Adaptor.

SAFETY

Certification	CE
Compliances	IEC 61010 CAT. III 600V over voltage and double insulation standard CE IEC61010, IEC61326, IEC61557

ACCURACY SPECIFICATION

Accuracy	± (% of reading) + (number of least significant digits) .
Operating Temperature	18°C ~ 28°C
Relative Humidity	45 ~ 75% RH

VOLTAGE MEASUREMENT

	DC Voltage	AC Voltage
Measurement Range	±30 ~ ±600V	30 V~ 600V(50/60Hz)
Resolution	1 V	
Accuracy	± (2% + 3)	

INSULATION RESISTANCE MEASUREMENT

Output Voltage	500V	1000V	2500V	5000V
Display Range	1MΩ ~ 5.5GΩ	2MΩ ~ 40GΩ	5MΩ ~ 100GΩ	10MΩ ~ 1000GΩ
Open Circuit Voltage	DC 500V 0% ~ +20%	DC1000V 0% ~ +20%	DC 2500V 0% ~ +20%	DC5000V 0% ~ +20%
Test Current	3.5mA @1MΩ	3.5mA @2MΩ	3.5mA @5MΩ	3.5mA @10MΩ
Short Circuit Current	>3.5mA			
Accuracy	0.0MΩ ~ 99.9M Ω : ±(3%+5) 100MΩ ~ 9.99G Ω : ±(5%+5) 10.0GΩ ~ 20.0G Ω : ±(10%+5)	0.0MΩ ~ 99.9M Ω : ±(3%+5) 100MΩ ~ 9.99G Ω : ±(5%+5) 10.0GΩ ~ 40.0G Ω : ±(10%+5)	0.0MΩ ~ 99.9M Ω : ±(3%+5) 100MΩ ~ 9.99G Ω : ±(5%+5) 10.0GΩ ~ 100.0G Ω : ±(10%+5)	0.0MΩ ~ 99.9M Ω : ±(3%+5) 100MΩ ~ 9.99G Ω : ±(5%+5) 10.0GΩ ~ 99.9G Ω : ±(10%+5) Above 100GΩ: [±(20%+5) Humidity :below 50%]

Note: All Specification are Subject to change without prior notice.

KUSAM-MECO[®]

AN ISO 9001:2008 COMPANY



DIGITAL INSULATION RESISTANCE TESTER

MODEL KM 2805MK-1

INSTRUCTION MANUAL

Title	Page No.
Introduction.....	05
Unpacking the Meter.....	05
Safety Information.....	06
International Electrical Symbols.....	08
Battery Saver (Sleep Mode).....	08
Battery Indication.....	08
The Meter structure.....	09
Display.....	12
Key Functions.....	14
Measurement Operation.....	17
A. Measuring Voltages.....	17
B. Measuring Insulation Resistance.....	19
a) Continuous Measurement.....	20
b) Timed Measurement.....	20
c) Polarization Index (PI) Measurement.....	21
d) Compare Function.....	22
The use of Power Adaptor.....	23

Title	Page No.
USB Interface.....	24
Maintenance.....	25
A. General Service.....	25
B. Replacing the Battery.....	26
Specifications.....	27
Safety and Compliances.....	27
Physical Specifications.....	27
General Specifications.....	28
Feature Summary.....	28
Detailed Accuracy Specifications.....	29
A. Voltage Measurement.....	29
B. Insulation Resistance Measurement.....	30
Test Certificate.....	31
Warranty.....	32

List of Tables

Table	Title	Page No.
1.	Unpacking Inspection.....	5
2.	International Electrical Symbols.....	8
3.	Battery Indication	8
4.	Meter Front Description	10
5.	Meter Side Description.....	11
6.	Display Description.....	13
7.	Key Description.....	14

List of Figures

Figure	Title	Page No.
1.	The Meter Front Structure.....	9
2.	The Meter Side Structure.....	11
3.	Display.....	12
4.	Voltages Measurement.....	17
5.	Insulation Resistance Measurement.....	19
6.	The Use of Power Adaptor.....	23
7.	USB Interface Connection.....	24
8.	Battery Replacement	26

Introduction

Model KM 2805 insulation Resistance Tester (hereafter, "the Meter") is a handheld instrument designed primarily to make resistance / insulation resistance measurement.

Unpacking the Meter

The Meter includes the following items :

Table 1. Unpacking Inspection

Item	Description	Qty.
1.	English Operating Manual	1pc
2.	One plug test lead to one alligator clip (Black colour)	1pc
3.	One plug test lead to one alligator clip (Green colour)	1pc
4.	Two plugs test lead to one alligator clip (Red colour)	1pc
5.	1.5V Battery (LR14)	8pcs
6.	Tool Box	1pc
7.	USB interface Cable	1pc
8.	Software	1pc
9.	Power Adaptor (input voltage 230V, 50/60Hz, 150mA, output DC 15V, 1100mA) (optionally, available at extra cost)	1pc

It is recommended to select the specific 8 pcs of #2 charging battery and a charger;
In the event you find any missing or damage, please contact your dealer immediately.

Safety Information

This Meter complies with the standards IEC61010 safety measurement requirement: in pollution degree 2, overvoltage category (CAT. III 600V) and double insulation.

CAT II: Local level, appliance, PORTABLE EQUIPMENT etc., with smaller transient voltage overvoltages than CAT. III.

Use the Meter only as specified in this operating manual, otherwise the protection provided by the Meter may be impaired.

 Danger identifies conditions and actions that pose hazard(s) to the user.

 Warning identifies avoiding electric shock.

 Caution identifies conditions and actions that may damage the Meter and carrying out accurate measurement.

 Operating Caution identifies conditions that user needs to take extra care during operating the Meter International electrical symbols used on the Meter and in this Operating Manual are explained on page 8.

DANGER

Use of instrument in a manual not specified by the manufacturer may impair safety features / protection provided by the equipment. Read the following safety information carefully before using or servicing the instrument.

- Do not apply more than 600V.
- Do not use the Meter around explosive gas, vapor or dust.
- Do not use the Meter in a wet environment.
- When using the test leads, keep your fingers away from the lead contacts. Keep your fingers behind the finger guards on the leads.
- Do not use the Meter with any parts or cover removed.

- When carrying out insulation measurement, do not contact the circuit under test.



WARNING

- Do not use the Meter if it is damaged or metal part is exposed. Look for cracks or missing plastic.
- Be careful when working above 33V rms, 46.7V AC rms or 70V DC. Such voltages pose a shock hazard.
- Discharge all loading of circuit under test after measuring high voltage.
- Do not change battery when the Meter is in wet environment.
- Place test leads in proper input terminals. Make sure all the test leads are firmly connected to the Meter's input terminals.
- Make sure the Meter is turned off when opening the battery compartment.



CAUTION

- When performing resistance tests, remove all power from the circuit to be measured and discharge all the power.
- When servicing the Meter, use only the same model number or identical electrical specifications of test leads and power adaptor.
- Do not use the Meter if the battery indicator() shows a battery empty condition. Take the battery out from the meter if it is not used for a long time.
- Do not use or store the Meter in an environment of high temperature, humidity, explosive, inflammable and strong magnetic field. The performance of the Meter may deteriorate after dampened.
- Soft cloth & mild detergent should be used to clean the surface of the Meter when servicing. No abrasive & solvent should be used to prevent the surface of the Meter from corrosion, damage and accident.
- Dry the Meter before storing if it is wet.

INTERNATIONAL ELECTRICAL SYMBOLS

International symbols on the Meter and in this Manual are explained in Table 2.

Table 2. International Electrical Symbols

- Risk of electric shock
- Equipment protected by double or reinforced insulation.
- DC Measurement
- AC Measurement
- Grounding
- See Manual
- Empty of Built-in Battery
- Conforms to Standards of European Union

Battery Saver (Sleep Mode)

The Meter enters the Sleep Mode and blanks the display if there is no button press for 15 minutes. This is done to conserve battery power. The Meter comes out of Sleep Mode when ON/OFF button is pressed and hold for 1 second.

Battery Indication

There is a battery indicator shows on the display upper left hand corner. Below Table 3 in the explanation.

Table 3. Battery Indication

Battery Indicator	Battery Voltage
	10V or less. It means the battery is empty, don't use the Meter as it cannot guarantee accuracy.
	10V~10.5V. It means the battery is nearly empty, replacing battery is necessary. At this status, the Meter can still do 500V and 1000V output measurement, accuracy will not be affected.
	10.6V ~ 11.5V
	11.6V or more

When Charging battery is applied, the charging battery work mode should be selected at the startup: press USB key prior to startup, then press down ON/OFF, LCD screen will display CHA or GEN, and CHA will be displayed by pressing the up/down key, after pressing USB key to confirm, it successfully enters the charging battery work mode. GEN means the general alkaline battery work mode.

The Meter Structure

Below Figure 1 and Table 4 shows the Meter front structure and description.




Table 4. Meter Front Description

1	LCD
2	Scroll Button
3	Emergency Stop
4	Data Clear the Display Backlight Button
5	Down Button
6	On/Off Button
7	Compare Button
8	Insulation Resistance Button
9	DC Voltage measurement Button
10	Timer Button
11	AC Voltages Measurement Button
12	Test Button
13	USB Button
14	Data Store Button
15	Data Recall Button
16	Scroll Button

17	Up Button
18	LINE : High Voltage output input terminal (two plugs red test lead to one alligator clip)
19	High Voltage line shielding input terminal (two plugs red test lead to one alligator clip)
20	GUARD : Grounding protection input terminal (one plug black test lead to one alligator clip)
21	EARTH : High resistance measurement input terminal (one plug green test lead to one alligator clip)
22	Testing leads : Two plugs red test lead to one alligator clip. One plug black test lead to one alligator clip. One plug green test lead to one alligator clip.

Below Figure 2 and Table 5 shows the Meter side structure and description




Figure 2. The Meter Side Structure

Table 5. Meter Side Description

1	Safety Shutter
2	Power adaptor Input Terminal
3	USB Port

Display

Table 6 & Figure 3 describe the display




Figure 3. Display

Table 6 DisplayDescription

Number	Meaning
1	Indicator for DC Voltage
2	Indicator for data store full
3	Indicator for clearing
4	Indicator for AC Voltage
5	Indicator for timer
6	Step Symbol
7	Indicates selected pass/fail compare value
8	Indicates for negative reading
9	Timer 1 symbol
10	Timer 2 symbol
11	Data store is on

Number	Meaning
12	Data recall is on
13	Indicator for polarization Index
14	Unit symbols
15	The continuity buzzer is on
16	Compare feature pass
17	Analogue bar graph
18	Risk of electric shock
19	Compare feature fail
20	Indicator for power adaptor
21	Battery life indicator

Key Functions

Table 7. Key Description

ON/OFF	Turn on or off the Meter, Press and hold the button for 1 second to turn the Meter on. Press again to turn off the Meter. The Meter default range is 500V insulation resistance continuous measurement when turning on.
LIGHT	Backlight open and close buttons.
CLEAR	Clear memory data key
SAVE	Press to store the current measurement value. The maximum number of stored reading is 18. When the stored readings memory is full, the Meter shows FULL & stop storing. Press and hold CLEAR to clear the stored value in order to store the next measurement value.

LOAD	<ul style="list-style-type: none"> • Press once to recall the first stored value. • Press again to exit load feature. • Load feature can only be used when there is no high voltage output.
	<ul style="list-style-type: none"> • When the insulation resistance measurement has no testing voltage output, press to select one voltage range up. • Under load mode:press to recall the previous stored value.
	<ul style="list-style-type: none"> • When the insulation resistance measurement has no testing voltage output, press to select one voltage range down. • Under load mode:press to recall the next stored value.

Table 7. Key Description

◀	<ul style="list-style-type: none"> • When set the timer duration for the measurement of insulation resistance or polarization index, press to decrement the time. The maximum length of time is 15 minutes and 30 seconds, the Meter will automatically carry out measurement. • When compare feature measuring insulation resistance, press to decrement a resistance comparing value. • After polarization index measurement, press to display polarization index, TIME2 insulation resistance value and TIME1 insulation resistance value in sequence. 	▶	<p>The maximum length of time is 30 minutes and 30 seconds, the Meter will automatically carry out measurement.</p> <ul style="list-style-type: none"> • When use the compare feature measuring insulation resistance, press to increment a resistance comparing value. • After polarization index measurement, press to display polarization index, TIME2 insulation resistance value and TIME1 insulation resistance value in sequence.
▶	<ul style="list-style-type: none"> • When set the timer duration for the measurement of insulation resistance or polarization index, press to increment the time. 	USB	<ul style="list-style-type: none"> • Press once to start the data transferring to the computer via USB, USB symbol shows on the display. • Press again to stop the data transferring to the computer via USB, USB symbol disappears.

Table 7. Key Description

COMP	Set a pass / fail limit for insulation tests. The default value is 10M .
TIME	Press to step through continuous measurement, timed measurement and polarization index measurement in sequence.
TEST	Press to stop or start an insulation resistance test.
IR	Press to initiate insulation resistance measurement.
DCV	Press to initiate DC Voltage measurement.
ACV	Press to initiate AC Voltage measurement.

Measurement Operation

Below section explains how to make measurements.

Press and hold **ON/OFF** to turn on the Meter, press again to turn off the Meter. The Meter default range is 500V insulation resistance continuous measurement when turning on.

A. Measuring Voltages




Figure 4. Voltages Measurement

 **Operating Caution**

- **To avoid harms to you or damages to the Meter, Please do not attempt to measure voltages higher than 600V or 600V rms, although readings may be obtained.**
- **Special care should be taken when measuring high Voltage.**

To measure voltages, set up the Meter as Figure 4 & do the following.

1. Press DCV or ACV button to select DC voltage or AC voltage measurement.
2. Insert the red and green test lead into the tested circuit.
3. When measuring DC voltage. If the red test lead is negative voltage “-” symbol will show on the display.

Note

- When voltage measurement has been completed, disconnect the connection between the testing leads and the circuit under test and remove testing leads away from the input terminals of the Meter.

B. Measuring Insulation Resistance




Figure 5. Insulation Resistance Measurement

⚠ Operating Caution

- When performing insulation resistance tests, remove all power from the circuit to be measured and discharge all the power.
- Operating the Meter must be very careful as it outputs dangerous Voltage during measurement. Must make sure the tested object is firmly clipped, hands are away from the clips, then press TEST button to put high Voltage.
- Do not short circuit the testing leads during high voltages output or test insulation resistance after high voltages output. This kind of incorrect operating may cause sparking and fire, which damages the Meter and harms to you.
- Do not measure over 10 seconds when :
 - 500V measure resistance lower than 2M Ω .
 - 1000V measure resistance lower than 5M Ω .
 - 2500V measure resistance lower than 10M Ω .
 - 5000V measure resistance lower than 20M Ω .

To measure insulation resistance, set up the Meter as Figure 5 and do the following :

1. Press **IR** button to select insulation resistance measurement.
2. When there is no testing voltage output, press **▲ & ▼** button to select voltages of 500V, 1000V, 2500V or 5000V.
3. When performing insulation resistance tests, remove all power from the circuit to be measured and discharged all the power.
4. Connect the red and green alligator clip to the measured circuit. The high voltage end originates from the LINE port.
5. Connect the red and black alligator clip to the circuit to be measured, negative voltage output from **LINE** terminal.
6. Choose below insulation resistance measurement mode.

A) Continuous Measurement

- Press **TIME** button to select continuous measurement mode, there is no timer icon on the LCD.
- Press **◀** and **▶** hold TEST button for 1 second to carry out continuous measurement. Output insulation resistance testing voltage, **TEST** button light up, **△** blinks on every 0.5 seconds.
- Press TEST button to close the insulation resistance measurement voltage when measurement is completed. TEST button lights off, **△** disappears. The LCD shows the current insulation resistance measurement value.

b) Timed Measurement

- Press **TIME** button to select timed measurement mode, the LCD displays **TIME 1** and **⌚** symbols.
- Press **◀** and **▶** buttons set the time (00:10~15.00). Within 1 minute, the time increment or decrement by every 10 seconds. Afterward, the time increment or decrement by every 30 seconds.

- Then press and hold **TEST** button for 2 second to carry out timed measurement. **TIME 1** and  are displayed and blinked on the LCD on every 0.5 seconds.
- When the set time is reached, the insulation resistance measurement voltage will be closed and the measurement will be automatically stopped. The LCD displays the insulation resistance reading.

c) Polarization Index (PI) Measurement

- Press **TIME** button to select timed measurement mode, the LCD displays **TIME 1** and  symbols.
- Press  and  buttons set the time (00:10~15.00). Within 1 minute, the time increment or decrement by every 10 seconds. Afterward, the time increment or decrement by every 30 seconds.
- Press **TIME** button again. **TIME 2, PI** and  symbols appear on the LCD.
- Press  and  buttons set the time (00:15~15.30). Within 1 minute, the time increment or decrement by every 10 seconds. Afterward, the time increment or decrement by every 30 seconds.

- Then Press and hold **TEST** button for 2 seconds to carry out timed measurement.
- **TIME 1** and  are displayed and blinked on the LCD on every 0.5 seconds before **TIME 1** set time is reached.
- **TIME 2** and  are displayed and blinked on the LCD on every 0.5 seconds before **TIME 2** set time is reached.
- When the two set time are reached, the insulation resistance measurement voltage will be closed and the measurement will be automatically stopped. The LCD displays the polarization index reading.
- Press ,  to set through the polarization index, **TIME 2** insulation resistance reading and **TIME 2** insulation resistance reading.

Information :

PI = 3 minutes ~10 minutes reading/30 seconds ~1 minute reading.

PI	4 or more	4 ~ 2	2.0 ~ 1.0	1.0 or less
Standard	The best	Good	Warning	Bad

d) Compare Function

- Press **COMP** button to select compare feature.
COMP symbol displays on the LCD.
- Press ◀ and ▶ buttons to set the compare value
- Below is the list in sequence of the compare value :
10M , 20M , 30M , 40M , 50M , 60M , 70M ,
80M , 90M , 100M , 200M , 300M , 400M ,
500M , 600M , 700M , 800M , 900M , 1G ,
2G , 3G , 4G , 5G , 6G , 7G , 8G , 9G , 10G ,
20G , 30G , 40G , 50G , 60G , 70G , 80G ,
90G , 100G , 200G , 300G , 400G , 500G ,
600G , 700G , 800G , 900G .
- Press and hold **TEST** button for 2 seconds to carry out the measurement.
- The **NG** symbol will display if the insulation resistance value is smaller than resistance value.
Otherwise **GOOD** symbol will be displayed.

The Use of Power Adaptor

The Use of Power Adaptor, see figure 6




Figure 6. The Use of Power Adaptor

1. Open the side safety shutter, then you will see there is a power adaptor input terminal.
2. Make sure the Meter is power off and insert the KM 2805MK-1 power adaptor to the input terminal.
3. It is highly recommended to take out all the batteries when you are using the power adaptor.
4. Make sure the Meter is power off when you disconnect the KM 2805MK-1 power adaptor from the Meter.
5. It is highly recommended to use KUSAM-MECO supplied KM 2805MK-1 power adaptor to avoid dangerous.

USB Interface

Connecting the USB interface, see figure 7




Figure 7. USB interface connection

1. Install the included software, the installation guide can be seen from the CD.
2. Open the side safety shutter, then you will see there is a USB port.
3. Insert the included USB cable to the Meter's USB port and the other end to the computer.

Maintenance

This section provides basic maintenance information including battery replacement instruction.

Warning

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information.

A. General Service

- Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.
- To clean the terminals with cotton bar with detergent, as dirt or moisture in the terminals can affect readings.
- Turn the Meter to OFF when it is not in use.
- Take out the battery when it is not using for a long time.
- Do not use or store the Meter in a place of humidity, high temperature, explosive, inflammable and strong magnetic field.

- If the Meter is wet, dry it before use.

B. Replacing the Battery




Figure 8. Battery Replacement

Warning

To avoid electric shock, remove all the test leads from the Meter when replacing the batteries.

Operating Caution

- Don't mix to use old and new batteries.
- Be careful the polarity is correct when installing batteries.
- Do not use the Meter if the battery indicator () shows a battery empty condition.
- Do you carry out measuring during the battery compartment is open.

Follow Figure 8 and proceed as follows to replace the battery :

- Turn the Meter to OFF and remove all connections from the terminals.
- Remove the screw from the battery compartment, and separate the battery compartment from the case bottom.
- Replace with 8pcs of new 1.5V (LR14) batteries.
- Rejoin the case bottom and battery compartment, and reinstall the screw.

Specifications

Safety and Compliances

Certification	CE
Compliances	IEC 61010 CAT III 600V over voltage and double insulation standard CE IEC61010, IEC61326, IEC61557.

Physical Specifications

Display (LCD)	Digital : 9999 counts Analog bar graph.
Operating Temperature	-10°C ~ 40°C (14°F ~ 104°F)
Storage Temperature	-20°C ~ 60°C (-4°F ~ 152°F)
Relative Humidity	85% @ 0°C ~ 40°C below; 90% @ -20°C ~ 60°C:
Battery Type	8 pcs of 1.5V (LR14) batteries or power adaptor (input voltage 230V, 50/60Hz, 150mA, input DC 15V, 1.0A). Power adaptor is optionally at extra cost.
Dimensions (H x W x L)	202 x 155 x 94 mm
Weight	Approx. 2kg (including battery)

General Specifications

Range	Auto
Overloading	Display OL on insulation resistance range
Battery Indicator	Display 
Icon Display	Equips with function and battery indicator icons.
Current Consumption	Maximum : around 1.0A Average : around 20 mA

Feature Summary

Display Backlight	Bright backlight for clear readings in poorly lighted areas.
Computer connection	Via USB interface.
Data Logging and Recall	18 points
Autorange	The Meter automatically selects best range
Warning	 and red light will on.
Voltage	Auto release voltage
COMP Measurement	Use the Compare function to set a pass/fail compare level for the insulation measurement.
PI Measurement	Polarization Index is the ratio of insulation resistance. You can pre-set two point of times and automatically carry out the measurement.
TIME	To carry out measurement by setting a specified time within 15 minutes.

Detailed Accuracy Specifications

Accuracy : \pm ([% of reading] + [number of least significant digits]), warrantee for 1 year.

Operating temperature : 18°C ~ 28°C

Relative humidity : 45 ~ 75% RH

A. Voltage Measurement

	DC Voltage	AC Voltage
Measurement Range	$\pm 30 \sim \pm 600V$	30V ~ 600V (50 / 60 Hz)
Resolution	1V	
Accuracy	$\pm (2\% + 3)$	

B. Insulation Resistance Measurement

Output Voltage	500V	1000V	2500V	5000V
Display Range	1M ~ 5.5G	2M ~ 40G	5M ~ 100G	10M ~ 1000G
Open Circuit Voltage	DC 500V 0%~+20%	DC 1000V 0%~+20%	DC 2500V 0%~+20%	DC 5000V 0%~+20%
Test Current	3.2mA @ 1M	3.2mA @ 2M	3.2mA @ 5M	3.5mA @ 10M
Short Circuit	Less than 3.5mA			
Accuracy	0.0M ~ 99.9M : $\pm(3\%+5)$ 100M ~ 9.99G : $\pm(5\%+5)$ 10.0G ~ 20.0G : $\pm(10\%+5)$	0.0M ~ 99.9M : $\pm(3\%+5)$ 100M ~ 9.99G : $\pm(5\%+5)$ 10.0G ~ 40.0G : $\pm(10\%+5)$	0.0M ~ 99.9M : $\pm(3\%+5)$ 100M ~ 9.99G : $\pm(5\%+5)$ 10.0G ~ 100.0G : $\pm(10\%+5)$	0.0M ~ 99.9M : $\pm(3\%+5)$ 100M ~ 9.99G : $\pm(5\%+5)$ 10.0G ~ 99.9G : $\pm(10\%+5)$ Above 100G : $[\pm(20\%+5)]$ Humidity : Below 50%

Operating Caution

At any output voltage, when the tested resistance is less than 10M , the testing time cannot exceed 10 seconds continuously.

MUMBAI
TEST CERTIFICATE

DIGITAL INSULATION RESISTANCE TESTER

This Test Certificate warrants that the product has been inspected and tested in accordance with the published specifications.

The instrument has been calibrated by using equipment which has already been calibrated to standards traceable to national standards.

MODEL NO. **KM 2805MK-1**

SERIAL NO. _____

DATE: _____

ISO 9001REGISTERED



WARRANTY

Each "KUSAM-MECO" product is warranted to be free from defects in material and workmanship under normal use & service. The warranty period is one year (12 months) and begins from the date of despatch of goods. In case any defect occurs in functioning of the instrument, under proper use, within the warrantee period, the same will be rectified by us free of charges, provided the to and fro freight charges are borne by you.

This warranty extends only to the original buyer or end-user customer of a "KUSAM-MECO" authorized dealer.

This warranty does not apply for damaged Ic's, burnt PCB's, fuses, disposable batteries, carrying case, test leads, or to any product which in "KUSAM-MECO's" opinion, has been misused, altered, neglected, contaminated or damaged by accident or abnormal conditions of operation or handling.

"KUSAM-MECO" authorized dealer shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of "KUSAM-MECO".

"KUSAM-MECO's" warranty obligation is limited, at option, free of charge repair, or replacement of a defective product which is returned to a "KUSAM-MECO" authorized service center within the warranty period.

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. "KUSAM-MECO" SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE WHATSOEVER.

All transaction are subject to Mumbai Jurisdiction.



17, Bharat Industrial Estate, T. J. Road, Sewree (W),
Mumbai-400015. INDIA

Sales Direct: 24156638 **Tel.:**(022)2412 4540, 2418 1649 **Fax:**2414 9659

E-mail : kusam_meco@vsnl.net,

Website : www.kusamelectrical.com, www.kusam-meco.co.in