

3³/₄ DIGITS AC/DC AUTORANGING DIGITAL CLAMPMETER

Model - KM 2720 - 17 FUNCTIONS 27 RANGES

KM 2725 - 17 FUNCTIONS 27 RANGES

SPECIAL FEATURES :

- High Resolution DCA / ACA of 1mA
- Auto Polarity display
- Auto Zero Adjustment
- Display annunciators for all functions & ranges
- Continuity & Diode Measurements
- Auto Power Off
- Low Battery Indication

GENERAL SPECIFICATIONS :

- * **Sensing :** Average sensing
- * **Jaw Size :** 23 mm
- * **Display :** 3³/₄ digits 4000 counts LCD display
- * **Sampling rate :** 2.5 reading / sec.
- * **Low Battery :** "BAT" mark is displayed when the Battery Voltage drops below 2.4V
- * **Over range indication :** Display "OL" or "-OL"
- * **Operating Temperature :** 0°C-50°C; 75% R.H.
- * **Storage Temperature :** -20°C to 60°C; 80% R.H. (Without battery)
- * **Power Supply :** 1.5V AAA battery x 2
- * **Dimension :** 183(L) X 43(W) X 31(H) mm
- * **Weight :** Approx. 200 gm (battery included)



KM2720

KM2725

ACCESSORIES :

Test leads, Carrying Case, Battery installed, User's Manual

ELECTRICAL SPECIFICATIONS- KM2720 / KM2725

Accuracy is ± (% reading digits + number of digits) or otherwise specified, at 23°C ± 5°C & less than 75% R.H.

AC/DC CURRENT (Model KM 2720)

Range	Resolution	Accuracy (ACA)	Accuracy (DCA)
40 A	10 mA	±(2.0%rdg + 3dpts)	±(2.0%rdg + 2dpts)
200 A	100 mA	±(2.5%rdg + 3dpts)	±(2.5%rdg + 2dpts)

AC/DC CURRENT (Model KM 2725)

Range	Resolution	Accuracy (ACA)	Accuracy (DCA)
4 A	1 mA	±(3.0%rdg + 3dpts)	±(3.0%rdg + 2dpts)
40 A	10 mA	±(2.0%rdg + 3dpts)	±(2.0%rdg ± 2dpts)

AC VOLTAGE

Range	Resolution	Accuracy
400 mV	100 V	±(1.8%rdg + 5dpts)
4 V	1 mV	±(1.0%rdg + 3dpts)
40 V	10 mV	±(1.0%rdg + 3dpts)
400 V	100 mV	±(1.0%rdg + 3dpts)
750 V	1 V	±(1.5%rdg + 3dpts)

Input Impedance : ≥10M

AC Voltage Test Frequency : 50Hz-500Hz for 400V & below, & 50Hz-100Hz for above 400V.

Overload Protection : DC 1000V or AC 750V rms

DC VOLTAGE

Range	Resolution	Accuracy
400 mV	100 V	±(1.0%rdg + 2dpts)
4 V	1 mV	±(0.8%rdg + 2dpts)
40 V	10 mV	±(0.8%rdg + 2dpts)
400 V	100 mV	±(0.8%rdg + 2dpts)
1000 V	1 V	±(0.8%rdg + 2dpts)

Input Impedance : ≥10M

Overload Protection : DC 1000V or AC 750V rms

CAPACITANCE

Range	Resolution	Accuracy
40 nF	10 pF	±(2.5%rdg + 10dpts)
400 nF	100 pF	±(2.0%rdg + 4dpts)
4 F	1 nF	±(2.0%rdg + 4dpts)
40 F	10 nF	±(2.5%rdg + 4dpts)


Overload Protection : 250V rms

RESISTANCE


Range	Resolution	Accuracy
400	100 m	±(1.0%rdg + 2dpts)
4 k	1	±(1.0%rdg + 2dpts)
40 k	10	±(1.0%rdg + 2dpts)
400 k	100	±(1.0%rdg + 2dpts)
4 M	1 k	±(1.0%rdg + 2dpts)
40 M	10 k	±(1.5%rdg + 2dpts)

Overload Protection : 250V rms

CONTINUITY TEST

Range	Description
	If the resistance is less than 100 Ω, the beeper sounds continuously

DIODE TEST

Range	Description
	Display read approx. Forward Voltage of diode. Accuracy : ±(3.0%rdg + 3dpts)

FREQUENCY

Range	Accuracy
9.999 Hz	Unspecified
99.99 Hz ~ 9.999 MHz	±(0.2%rdg + 3dpts)

Sensitivity : Frequency - 0.7V AC rms; Voltage - 0.1V AC rms

Overload Protection : 250V rms

DUTY CYCLE

Range	Resolution	Sensitivity
0.1%~99.9%	0.1%	Frequency - 0.7V AC rms; Voltage - 0.1V AC rms

Overload Protection : 250V rms

All Specifications are subject to change without prior notice

LIST OF PRODUCTS

- * Digital Multimeter
- * Digital AC & AC/DC Clampmeter
- * AC Clamp Adaptor
- * AC/DC Current Adaptor
- * Transistorised Electronic Analog & Digital Insulation Resistance Testers
- * Digital Sound Level Meter & Sound Level Calibrator
- * Digital contact & Non-contact Type Tachometer
- * Digital Non-contact (infrared) Thermometer
- * Thermo Hygrometer
- * Thermo Anemometer
- * Wood Moisture Meter
- * Distance Meter
- * Digital Hand Held Temperature Indicators
- * Digital Lux Meter
- * Network Cable Tester
- * Power Factor Regulator
- * Maximum Demand Controller/Digital Power Meter

KUSAM-MECO

17, Bharat Industrial Estate, T. J. Road, Sewree (W),
Mumbai-400015. INDIA

Sales Direct: 24156638 Tel.:(022)2412 4540, 2418 1649 Fax:(022)2414 9659

E-mail : kusam_meco@vsnl.net, Website : www.kusamelectrical.com
www.kusam-meco.co.in

KUSAM-MECO

**AUTORANGING
CLAMP METER
KM 2720 / KM 2725**

**OPERATION
MANUAL**

KUSAM-MECO

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. "KUSAM-MECO" SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE WHATSOEVER.

All transaction are subject to Mumbai Jurisdiction.

KUSAM-MECO

G 17, Bharat Industrial Estate, T. J. Road,
Sewree (W), Mumbai - 400 015. INDIA.

Sales Direct : (022) 24156638

Tel. : (022) 24124540, 24181649.

Fax : (022) 24149659

Email : kusam_meco@vsnl.net

Website : kusam-meco.co.in, kusamelectrical.com

KUSAM-MECO

AUTORANGING CLAMPMETER KM 2720 / KM 2725



**TAKE MEASUREMENT CAREFULLY AND YOU'LL
SPARE YOUR METER AND YOURSELF, SOME PAIN**

Nearly every electrical engineer has a hand held digital clamp meter (Tongtester). We sometimes take them for granted, until we damage them or "burn them out". If you incorrectly connect your clamp meter to a circuit, or if you have the clamp meter on wrong setting, you damage the meter and possibly hurt yourself. You can also get into trouble if you try to measure the voltage across a charged capacitor.

Clamp meter users frequently burn their meters by trying to measure current the same way as they measure voltage. Remember, you measure voltage **across** a circuit, and current **through** a circuit. When you use the current input, your clamp meter becomes a low impedance circuit element.

Even if you correctly insert your clamp meter in to the circuit, you can still damage your meter. Don't try to measure current in excess of your meter's capacity. Check the current capacity of the Clamp meter first.

If you are measuring current in industrial environment, to prevent excess current from flowing through your meter, always disconnect your test leads from the circuit under test whenever you change Clamp meter functions. Set your meter to the correct function, say current, and its highest range for the setting. If the reading is small, change the range to the next lower range till the reading can be read with the best possible accuracy. When measuring voltage, connect the test leads before your apply power to your circuit. To be safe, start by setting your meter to its highest range first.

WARRANTY

Each "KUSAM-MECO" product is warranted to be free from defects in material and workmanship under normal use & service. The warranty period is one year (12 months) and begins from the date of despatch of goods. In case any defect occurs in functioning of the instrument, under proper use, within the guarantee period, the same will be rectified by us free of charges, provided the to and fro freight charges are borne by you.

This warranty extends only to the original buyer or end-user customer of a "KUSAM-MECO" authorized dealer.

This warranty does not apply for damaged Ic's, fuses, disposable batteries, carrying case, test leads, or to any product which in "KUSAM-MECO's" opinion, has been misused, altered, neglected, contaminated or damaged by accident or abnormal conditions of operation or handling.

"KUSAM-MECO" authorized dealer shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of "KUSAM-MECO".

"KUSAM-MECO's" warranty obligation is limited, at option, free of charge repair, or replacement of a defective product which is returned to a "KUSAM-MECO" authorized service center within the warranty period.

MUMBAI

TEST CERTIFICATE
AUTORANGING CLAMPMETER

This Test Certificate guarantees that the product has been inspected and tested in accordance with the published specifications.

The instrument has been calibrated by using equipment which has already been calibrated to standards traceable to national standards.

MODEL NO. _____

SERIAL NO. _____

DATE: _____

ISO 9001
REGISTERED



TABLE OF CONTENTS

TITLE	PAGE
Safety.....	1
General Features.....	2
Electrical Specifications.....	3
DC/AC Current	
DC/AC Voltage	
Frequency & Duty	
Resistance	
Diode & Continuity	
Capacitance	
Push button.....	5
Measurement.....	6
DC/AC Current Measurement	
DC/AC Voltage Measurement	
Frequency & Duty Cycle Measurement	
Resistance Measurement	
Diode & Continuity Test	
Capacitance Measurement	
Auto Power Off	
Maintenance.....	9
Battery Replacement.....	10
Fuse Replacement.....	10
Test Certificate.....	11
Warranty.....	13

GENERAL INSTRUCTION


The KM 2720 / KM 2725 is a handheld digital clamp meter with auto range & auto power off functions. It can test the AC/DC Current & Voltage, Frequency, Resistance, Diode, etc. It is ideal instrument for use in many fields, such as industry, scientific, training and electric department.

1) SAFETY INFORMATION

The following safety information must be observed to insure maximum personal safety during the operation at this meter:

- 1.1 Do not use the meter if it looks damaged.
Inspect the leads for damaged insulation or exposed metal, check test lead continuity, and replace the damaged leads.
- 1.2 Do not measure with high voltage (above DC 1000V or AC 750V).
- 1.3 Be cautions when working at DC60V or AC30V, such voltage may cause a shock hazard.
- 1.4 When making measurements, keep your finger behind the guard's plant on the probes for safety.

6.2 Battery Replacement

The meter is powered by two 1.5V, R6 Um3 AA SIZE carbon zinc or alkaline battery, Replace battery if the low battery sign "" is displayed.

1. Set the rotary switch to "OFF" position.
2. Loosen screws on bottom cover, pull up and move the cover.
3. Replace the defective battery.
4. Reverse the procedure of opening cover to close the bottom cover.

6.3 Fuse Replacement

1. Perform steps 1 to 2 of battery replacement procedure.
2. Replace the defective fuse and use same size and rating install in the fuse holder.
3. Reverse the procedure of opening cover to close the bottom cover.

6. Maintenance

WARNING


To avoid electrical shock or damage the meter' do not get water inside the case. If the meter fails to operate, check battery, test leads, fuse, etc., And replace them if necessary. If the meter still does not work, double check operating procedure as described in this manual.

6.1 Maintenance

The meter is a precis product. Please do not promiscuously change the circuit or regulation-resistance. And pay attention to following :

1. Do not use the Resistance, Diode, Transistor or Current range to test Voltage.
2. Only replace the battery or Fuse when remove the probe and power off.
3. Avoid damp, high temperature, greasy dirt and strong magnetic field when storage.
4. Please power off the meter when not using. Take out of the battery if it is not used for a long time.

2. GENERAL FEATURES

Display	: 3 ¾ digits LCD display with 3999 counts.
Over range indication	: Display "OL" or "-OL"
Auto Function	: Auto range, Auto power off, Auto polarity display, Auto zero adjustment, Auto units display.
Reading Rate	: 2.5 reading / Sec.
Low battery indication	: "  " mark is displayed when the battery voltage drops below 2.4V.
Operating Temperature	: 0°C to 50°C, ≤70%RH
Storage Temperature	: -20°C to 60°C, ≤80%RH (Without Battery)
Power supply	: R6 Um3 "AA" 1.5V x 2
Dimension	: 183(L) x 43(W) x 31(H)mm
Weight	: Approx. 200g (including Battery)

3. ELECTRICAL SPECIFICATIONS

AC CURRENT (Model KM 2720)

Range	Resolution	Accuracy
40A	0.01A	± 2.0%rdg ± 0.03
200A	0.1A	± 2.5%rdg ± 0.3

DC CURRENT (Model KM 2720)

Range	Resolution	Accuracy
40A	0.01A	± 2.0%rdg ± 0.02
200A	0.1A	± 2.5%rdg ± 0.2

AC CURRENT (Model KM 2725)

Range	Resolution	Accuracy
4A	0.001A	± 2.0%rdg ± 3d
40A	0.01A	± 2.0%rdg ± 3d

DC CURRENT (Model KM 2725)

Range	Resolution	Accuracy
4A	0.001A	± 2.0%rdg ± 2d
40A	0.01A	± 2.0%rdg ± 2d

AC VOLTAGE(Model KM 2720 & KM 2725)

Range	Resolution	AC Accuracy
400 mV	0.1 mV	± 1.8%rdg ±5d
4 V	1 mV	± 1.0%rdg ±3d
40 V	10 mV	± 1.0%rdg ±3d
400 V	0.1 V	± 1.0%rdg ±3d
750 V	1 V	± 1.5%rdg ±3d

Note : Input Resistance : ≥ 10MΩ.

AC Voltage test Frequency : 50Hz ~ 500Hz for 400V and below, 50Hz~100Hz for above.

Over load protect : DC 1000V or AC 750V RMS.

5.5 Diode and Continuity Test

CAUTION

To avoid damage to the meter or to the equipment under test, Disconnect circuit power and discharge all high-voltage capacitance before measuring Diode or Continuity.

1. Set the rotary switch to " →|→ »)" position.
2. Press to select " →|→ " or " »)" test mode.
3. Connect the black test lead to "COM" terminal and the red test lead to "V Ω" terminal.
4. Touch the probes to the two ends of diode. For diode, a good diode should display a forward-bias reading of 0.3V to 0.8V. However, the reverse-bias reading will be over range and appears "OL" on display. A shorted circuit diode reading is near 0V, open circuit diode appears "OL" in both directions. For continuity, if the test points resistance below 100Ω, the beeper sounds.

5.6 Capacitance measurement

1. Set the rotary switch to "CAP" position. Touch the probes to tested capacitor and get reading.
2. Connect the black test lead to "COM" terminal and red test lead to "V Ω" terminal.

NOTE : When testing the large capacitor, please discharge the capacitor first by short circuit. This meter use charge method to test the capacitor, so it will take long time to get the rading if testing the large capacitor.

5.7 Auto power off

When the meter is auto switch off, it will be awaken to work state by turning the function switch or pressing any button.

5.2 DC/AC Voltage Measurement

1. Set the rotary switch to “V” position. Press **REL/SELECT** button to select DC or AC mode according to test voltage.
2. Connect the black test lead to “COM” terminal and the red test lead to “VΩ” terminal.
3. Touch the probes to the test points and get reading.

5.3 Frequency and duty cycle Measurement

1. Set the rotary switch to “Hz” position. Touch the probes to signal source and get reading.
2. Connect the black test lead to “COM” terminal and the red test lead to “VΩ” terminal.
3. Press **REL/SELECT** to select Hz or DUTY test mode.

5.4 Resistance Measurement

CAUTION

To avoid damage to the meter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitance before measuring resistance.

1. Set the rotary switch to “Ω” position.
2. Connect the black test lead to “COM” terminal and the red test lead to “VΩ” terminal.
3. Touch the probes to test points or resistance and get reading.

DC VOLTAGE(Model KM 2720 & KM 2725)

Range	Resolution	Accuracy
400 mV	0.1 mV	± 1.0%rdg ± 2
4 V	1 mV	± 0.8%rdg ± 2
40 V	10 mV	± 0.8%rdg ± 2
400 V	0.1 V	± 0.8%rdg ± 2
1000 V	1 V	± 0.8%rdg ± 2

Note : Input Resistance : ≥ 10MΩ.
 AC Voltage test Frequency : 50Hz ~ 500Hz for 400V and below, 50Hz~100Hz for above.
 Over load protect : DC 1000V or AC 750V RMS.

FREQUENCY AND DUTY CYCLE RANGE (Model KM 2720 & KM 2725)

Range	Accuracy	Sensitivity
9.999Hz	Unspecified	Frequency: 0.7V AC RMS Voltage : 0.1V AC RMS
99.99Hz-9.999MHz	± 0.2%rdg ± 3	
DUTY Range : 0.1% to 99.9%		

Note : Overload Protection : 250V RMS

RESISTANCE

Range	Resolution	Accuracy
400 Ω	0.1 Ω	± 1.0%rdg ±2d
4 kΩ	1 Ω	± 1.0%rdg ±2d
40 kΩ	10 Ω	± 1.0%rdg ±2d
400 kΩ	100 Ω	± 1.0%rdg ±2d
4 MΩ	1 kΩ	± 1.0%rdg ±2d
40 MΩ	10 kΩ	± 1.5%rdg ±2d



Note : Overload Protection : 250V RMS

CAPACITANCE (Model KM 2720 & KM 2725)

Range	Resolution	Accuracy
40 nF	10 pF	± 2.5%rdg ±10d
400 nF	100 pF	± 2.0%rdg ± 4d
4 μF	1 nF	± 2.0%rdg ± 4d
40 μF	10 nF	± 2.5%rdg ± 4d

Note : Overload Protection : 250V RMS



DIODE & CONTINUITY TEST (Model KM 2720 & KM 2725)

Range	Description
	Display read approx. Forward voltage of diode. Accuracy : ±(3.0%rdg + 3)
	If the resistance is less than 100Ω, the beeper sounds continuously

4. PUSH BUTTON

4.1 REL/SELECT BUTTON

Press **REL** to automatic zero adjustment.

Press **SELECT** to select DC or AC and  or  mode.

4.2 RANGE BUTTON

Press this button to enter the manual range mode.

Press **RANGE** more than 2 seconds, return to auto range mode (except for Frequency range).

4.3 HOLD BUTTON

Press this button to enter data hold mode.

5. MEASUREMENT

5.1 DC/AC Current Measurement

WARNING

To avoid damage to the meter or injury if the fuse blows, never attempt to make an in-circuit current measurement where the open-circuit potential to earth is greater than 1000V. To avoid damage to the meter, check the meter's fuses before proceeding. Use the proper terminals, function, and range for your measurement. Never place the probes in Parallel with a circuit or component when the test leads are plugged into the current terminals.

1. Set the rotary switch to AC or DC 40A & 200A position. Then press **REL/SELECT** to auto adjust zero.(KM 2720)
2. Set the rotary switch to AC or DC 4A & 40A position. Then press **REL/SELECT** to auto adjust zero.(KM 2725)
3. Open the jaw and clamp on the wire under testing and get reading.
Node : Test one wire each time.
4. If you want to keep the test data, press the **HOLD** button and get reading.