


Model KM-20-5030(30MHz) / KM-20-5060(60MHz)

**FEATURES :**

- DC-30MHz / DC-60MHz
- Dual channels /dual traces, X-Y mode
- 6" display, high brightness Toshiba oscilloscope tube
- High sensitivity of triggering, up to 1mV/division
- Ch1 channel incremental magnification function for clearer observation than ordinary oscilloscope.
- TV synchronous separation circuit for displaying stable TV signal
- Trigger mode : AUTO/ NORM / TV-V/ TV-H
- Vertical : CH1/ CH2 /ALT/ CHOP/ADD
- X-x10 / Y-x5
- Polarity inversion
- CH1 Channel incremental magnification function for clearer observation than ordinary Oscilloscope (KM-20-5060)



Preliminary Data

**GENERAL & ELECTRICAL SPECIFICATIONS :**

- CRT : 6 inch rectangular screen with internal graticule ,8 x10 div (1 div = 1cm)
- Vertical deflection :  
Display mode : CH1 , CH2, ADD, ALT, CHOP  
Deflection factor : 5mV / div to 5V/ div  $\pm$  3%, 1mV/ div to 1V/div  $\pm$  5% (X5), 10 steps
- Rise time : 17.2ns (KM-20-5030); 8.8ns (KM-20-5060)
- Max. Input voltage : 250V (DC + AC peak) 1KHz
- Input coupling : AC, DC, GND
- Polarity selection : + or - (CH2 only)
- Horizontal deflection :  
Display mode : 1, 10, X - Y  
Time Base : 0.2 s / div to 0.2s / div , 9 ranges  
Sweep magnification : X10  
CH1 ALT Magnification : X10  
Accuracy :  $\pm$  3%
- Trigger System :  
Trigger mode : NORM, AUTO, TV-V, TV-H  
Trigger source : CH1, CH2, VERT, LINE, EXT
- Sensitivity and frequency : 20Hz ~ 30MHz (VERT) (KM-20-5030); 20Hz ~ 60MHz (VERT) (KM-20-5060)  
AUTO , NORM : 0.5div(INT), 5Vp-p(EXT) (KM-20-5030); 1.5div(INT), 8Vp-p(EXT) (KM-20-5060)  
TV-V , TV-H : At least 1 div or 1Vp-p
- Input impedance : 1M
- X - Y Operation  
X - Y Phase difference : 3°, DC - 50KHz
- Calibration waveform : Frequency : 1KH  $\pm$  20%, Voltage : 0.5V  $\pm$  10%
- Power supply : 220V / 110V  $\pm$  10% ; 50 / 60Hz
- Dimensions : 310(W) x 130(H) x 370(D)mm
- Weight : approx. 6.5Kg


**ACCESSORIES :**

Probe , Power Cord , User's Manual

All Specifications are subject to change without prior notice

**KUSAM-MECO®**

AN ISO 9001:2000 COMPANY



## **DIGITAL ANALOG STORAGE OSCILLOSCOPE**

**MODEL KM 20-5030 /  
KM 20-5060**

**INSTRUCTION MANUAL**

## CONTENTS

<b>Title</b>	<b>Page No.</b>
1. Features.....	1
2. Accessories.....	1
3. Precautions.....	2
4. Controls And Connectors.....	5
5. How To Produce the Bright Line.....	12
6. Method For Connecting Signals.....	14
7. Measuring Procedure.....	16
8. Adjustments.....	26
9. Maintenance.....	27
10. Specifications.....	27
11. External View.....	31
12. Test Certificate.....	32
13. Warranty.....	33

## 1. FEATURES

The V-5060/V552 is a portable-type, advanced-class oscilloscope with a bandwidth of DC to 60 MHz /50MHz designed with the emphasis on operability and portability and has a following features.

**(1) Wide bandwidth**

The instrument has a bandwidth from DC to 60 MHz  
50MHz

**(2) High sensitivity**

Sensitivity is 1 mV/div

**(3) Large 6 " screen:**

Employment of a large square CRT makes waveforms easier to observed

**(4) internal graticule:**

Employment of an internal graticule CRT permits waveforms observation to be made without parallax error

**(5) DC OFFSET:**

Allows a proportionate observation of any part of an input waveform even when it is in a large amplitude.

**(6) ALTMAG**

Allows simultaneous observation of X1 and X10 sweeping waveforms

**(7) ALT TRIG**

Even an observation of two waveforms of different frequencies, the waveform of the each channel is stably triggered.

**(8) TV synchronization**

Employment of a new TV sync separator circuit allows the instrument to observe TV signals stably.

**(9) Auto focusing**

Focusing shift is automatically corrected.

## 2. ACCESSORIES

This instrument is shipped with the following standard accessories.

2 Probes

V-5060: MEI LI (1:10)

V-552 : MEI LI ( :10)

1 AC power supply cord

1 Operation manual

In case of (EM) TYPE : Without Probes



### 3. PRECAUTIONS

Precautions to be observed to lengthen the service life of this instrument.

#### Installation site

- \* Avoid installing instrument in an extremely hot or cold place
  - Avoid placing this instrument in a place exposed to sunlight for a long period of time, in a closed car in mid-summer, or near a room heating device such as a stove
  - The operating maximum ambient temperature is +40°C
- \* Do not use instrument that has been left outdoors on a cold winter day.

The operating ambient temperature is 0°C or more



- \* Avoid moving the instrument rapidly from a hot place to a cold place or vice versa, or condensation may form on the instrument.
  - \* Keep the instrument away from damp air, inside of the instrument water and dust.
- Unexpected trouble may be caused when the instrument is placed in a damp or dusty place.

The operating ambient humidity is 35-85%  
Since an accidental intrusion of water may also cause troubles, do not place a water-filled container such as a vase near the oscilloscope




- \* Do not place the instrument in a place where vibration is strong. Avoid using the instrument at a place vibrating violently. Since the oscilloscope is a precision instrument, excessively strong vibrations may cause damage.
- \* Do not place the instrument near a magnet or magnetic body. An oscilloscope is an equipment using an electron beam. Therefore, do not bring a magnet close to the instrument or do not use the instrument near an equipment generating strong magnetic force.



#### Handling

- \* Do not put heavy objects on the oscilloscope.
- Do not block the ventilation holes.

\* Do not apply a heavy shock to the oscilloscope




\* Do not insert a wire, pin, etc. through the ventilation hole.  
Do not drag the set, leaving the probe attached to it.



Do not leave a hot soldering iron on the cabinet or the screen.

Do not try to turn the instrument upside down. Otherwise, knobs may be broken



Do not use the instrument upright, leaving BNC cable connected to EXT BLANKING terminal on the rear panel. Otherwise, the cable may be damaged.



#### When operation is faulty

Recheck the operating procedure and if problem persists contact a nearby service station of agent.

#### Care and repair

Removal of stain from the case

When the outside of the case is stained, remove the stain by first wiping it lightly with a cloth moistened with neutral washing agent and then wipe the surface with a dry cloth

Never use strongly volatile agent such as benzine and thinner.



- When the panel surface is stained, remove the stain in similar way with a clean a clean, soft cloth. When heavy stains are present, first remove the stains by wiping the surface lightly with a cloth moistened with diluted neutral washing agent or with alcohol and then wipe thoroughly with a dry cloth.
- When dust has accumulated on the inside, remove it by using dry brush, or by using the exhaust of a compressor or a vacuum cleaner. By a SERVICE PERSONNEL.

**NOTE:** When opening the case ,pull out the power supply plus beforehand without fail.

When cleaning the inside, insure beforehand that no electricity remains in the condensers of the power supply circuit." NOT FOR AN OPERATOR"

#### **Operation precautions**

prior to shipment, the voltage selector is set property. When the oscilloscope is intended to be used on a different Voltage, re locate the voltage selector in the procedures which follow.

- 1) Disconnect the power connector.
- 2) Insert a screwdriver into the right side or the cap and remove the fuse holder cap.
- 3) Mount the fuse holder cap in to the fuse holder so that the marking of the correct voltage faces up.
- 4) Connect the power connector.

- \* Do not increase the brightness too much.  
Do not increase the brightness of the spot and trace too much your. Eyes may be strained and the fluorescent surface of CRT may be burnt.

- \* Do not apply an excessive voltage.  
The input withstand voltage of each input connector and probe input is as follows. Never apply a voltage higher than specified.


INPUT direct,	300V (DC+AC peak at 1 kHz)
When $\times 10$ probe is used	400V (DC+AC peak at 1 kHz)
When $\times 1$ probe is used	300V (DC+AC peak at 1 kHz)
EXT TRIG INPUT	300V (DC+AC peak )
EXT BLANKING	30V (DC+AC peak )

#### **Calibration Interval**

To maintain instrument accuracy, performs the calibration of the V-5060 / V-552 at least every 1000 hours of operation, or every months if used infrequently.



**4. CONTROLS AND CONNECTORS**



① **POWER switch**

The POWER is set on at the pushed-in position, and set off at the released position

② **Power lamp**

This lamp goes on when the power supply is in ON state.

③ **FOCUS control**

After obtaining an appropriate brightness by operating INTENSITY, adjust FOCUS until the bright line is clearest. Although the focus is also corrected automatically when INTEN is rotated, the focus is sometimes slightly shifted.

④ **SCALEILLUM control**

Controls graticule illumination Useful to illuminate the graticule when viewing in a dark area, photographing.

⑤ **TRACE ROTATION control**

Used to align the trace of CRT with the horizontal graticule.

⑥ **INTENSITY control**

This knob also works as the brightness adjust variable resistor. Brightness is increased by rotating INTENSITY

clockwise

⑦ **FUSE**

⑧ **AC INLET**

This is inlet for detachable AC power cord.

(2) Controls of vertical deflection system

⑨ **CH1 INPUT connector**

BNC connector for vertical axis input.

The signal input to this terminal becomes the X-axis signal when the instrument is used as an X-Y oscilloscope.

⑩ **CH2 INPUT connector**

The same as Ch1, but when the instrument is used as an X-Y oscilloscope, the signal input to this terminal becomes the Y-axis signal.

⑪⑫ **Input coupling switches(AC-GND-DC)**

The switches used to select the coupling system between the input signal and vertical axis amplifier.

AC At this setting the signal is connected through a condenser. The DC component of the input signal is cut off and only the AC component is displayed.

**GND** At this setting the input to the vertical axis amplifier is grounded.

**DC** At this setting the input signal is directly connected to the vertical axis amplifier and displayed unchanged, including the DC component.

**⑬ ⑭ VOLTS/DIV select switches**

A step attenuator which selects vertical deflection factor. Set it to an easily observable range corresponding to the amplitude of the input signal.

Multiply the reading by 10 when the 10:1 probe is used in combination with the instrument.

**⑮ ⑯ VAR PULL × 5 GAIN controls**

Fine tuning device used to vary the vertical deflection sensitivity continuously. Attenuation of less than 1/2.5 is obtained when this device rotated in the reverse direction of the arrow to the full.

This control is used when comparing waveforms or when measuring the rise time of a square wave in 2-channel observation. Normally this control is left rotated in the direction of the arrow to the full. When the knob is at PULL position (pulled up state) the gain, of the vertical axis is magnified 5 times and the maximum sensitivity becomes 1mV/DIV.

**⑰ ⑱ UNCAL lamp**

Light when VAR is out of CAL detent position

**⑲ POSITION control**

**PULL DC OFFSET**

This knob used to adjusting the position of the vertical axis.

The image rises with the clockwise rotation of this knob and falls with the counterclockwise rotation.

When the knob is pulled up, the adjustment range of the trace position of the vertical axis can be magnified by the DC OFFSET function. Therefore, the peak value of an input waveform with large amplitude can be measured. (keep pushed-in for the normal operation.)

**⑳ POSITON control**

**PULL INVERT control**

The same as CH1, but when the knob is at PULL position (pulled up state), this is used to inverse the polarity of the input signal applied to CH2.

This control is conveniently used in the comparison of two waveforms having different polarity or in the observation of the waveform of the difference signal (CH1)-(CH2) between CH1 and CH2 using ADD.

**㉑ MODE select switch**

This switch is used to select the operation mode of the



Vertical deflection system.

**CH1** Only the signal that has been applied to CH1 appears on the screen.

**CH2** Only the signal that has been applied to CH2 appears on the screen.

**ALT** Signals applied respectively to CH1 and CH2 appear on the screen alternatively at each sweep. This setting is used when the sweep time is short in 2-channel observation.

**CHOP** At this setting the input signals applied respectively to CH1 and CH2 are switched at about 250kHz independent of the sweep and at the same time appear on the screen, This setting is used when the sweep time is long in 2-channel observation.

**ADD** The algebraic sum of the input signals applied respectively to CH1 and CH2 appears on the screen.

**22 CH1 OUTPUT connector**

Output connector providing a sample of the signal applied to the CH1 connector.

**23 DC OFFSET VOLTOUT**

This is the output connector to readout the voltage measurement with a digital multi-meter, etc., when the

instrument is set to the DC OFFSET mode.  
( Except :  $\times 5$  GAIN, out of CAL)

**24 25 DC BAL adjustment controls**

These are used for the ATT balance adjustment. See .8 ADJUSTMENTS . . For the details. Controls of Horizontal deflection system

**26 TIME/DIV select switch**

Sweep time ranges are 19 steps from 0.2 us/div to 0.2s/div.

**X-Y** This position is used when using the instrument as an X-Y oscilloscope.

In this position the X(horizontal) signal is connected to the input of CH1; the Y (vertical) signal is applied to the input of CH2 and has a deflection range from less than one millivolt to 5 volts /div at a reduced bandwidth of 500kHz.

**27 SWP VARIABLE control**

This control works as CAL and the sweep time is calibrated to the value indicated by TIME/DIV TIME/DIV. Of sweep can be varied continuously when shaft is out of CAL position.

Then the control is rotated in the direction of arrow to the full, the CAL state is produced and the sweep time

is calibrated to the value indicated by TIME/DIV.  
Counterclockwise rotation to the full delays the sweep by 2.5 times or more.

⑳ **Sweep UNCAL lamp**


Light when SWP VAR is out of CAL detent position.

㉑ **POSITION control**  
**PULL × 10MAG**

This knob is used to move the bright line in horizontal directions. It is indispensable in the measurement of the time of waveform.

Bright line is move toward right when the knob is rotated clockwise and toward left with counterclockwise rotation.

Sweep is magnified 10 times by pulling out knob of POSITION. In this case the sweep times is 1/10 of the value indicated by TIME/DIV. Bring the position of the waveform desired to be magnified observed to the outer of the scale by operating ◀ ▶ POSITION of the horizontal axis. Next, switch x 10MAG switch to PULL (pulled out state). Then the waveform placed at the center is magnified in right and left directions. The sweep time in this case is 10 times the sweep speed obtained by TIME/DIV, in other words, the reading is 1/10 of the sweep time indicated.



- ⑳ **CH1 ALT MAG** *(only for model 5060)*  
CH1 input signal is displayed alternately by each single sweep of × 1 (NORM) and × 10 (MAG)  
set the wished portion of the waveform to the screen center for magnification.  
The × 10 waveform, appears 3 divisions below the × 1 waveform.

#### (4) Synchronization system

##### ① SOUKCE select switch

This switch is used to select the triggering signal source sweep.

**INT** The input signal applied to CH1 or CH2 becomes the triggering signal

**LINE** This setting is used when observing a signal triggering with power supply line frequency.

**EXT** External triggering signal applied to TRIG INPUT becomes the triggering signal.  
This setting is used when triggering with a special independently of the vertical axis signal.

##### ② INT TRIG select switch

This switch is used to select the internal triggering signal source sweep.

**CH1** The input signal applied to CH1 becomes the triggering signal,

**CH2** The input signal applied to CH2 becomes the triggering signal.

##### VERT

**MODE** For observing two waveforms, the sync signal changes alternately corresponding to the signals on CH1 and CH2 to trigger the signal.

##### ③ TRIG IN put connector


Input terminal for use for external triggering signal of sweep

##### ④ TRIG LEVEL control

This knob is used to decide at which portion of the waveform should the sweep be started by setting trigger level. This knob is also enabled to switch SLOPE.



Depressed position (normal state) is for  $\oplus$  SLOPE and PULL position (state in which the knob is protruding) is for  $\ominus$  SLOPE

##### Explanation of synchronization polarity SLOPE





**Explanation of synchronization level LEVEL**



**③⑤ TRIG MODE select switch**

**AUTO** The instrument is brought into automatically triggering sweep in which sweep is always conducted.

In the presence of triggered signal, normal triggered sweep is obtained and the waveform stands still. In the case of no signal or out of triggering, sweep line will appear automatically

**NORM** This setting is convenient in usual cases.

Triggered sweep is obtained and sweep is conducted only when triggering is effected, No

Sweep line will appear in the case of no signal or out of synchronization, Use this MODE when effecting synchronization to a very low frequency signal(25Hz or less).

**TV(H)** This setting is used when observing the entire vertical picture of television signal.

**TV(H)** This setting is used when observing the entire horizontal picture of television signal.

(NOTE) Both TV V and TV H synchronize only when the synchronizing signal is negative.

**(5) Miscellaneous**

**③⑥ EXT BLANKING connector**

Input terminal for brightness modulation. It is of the DC coupling. The brightness is reduced with a positive signal and increases with a negative signal.

**③⑦ CAL 0.5V tip**

Output terminal of calibration square wave of about 1 kHz and 0.5v .It has a tip terminal. It is used to calibrate the probe combination.

**③⑧ GND terminal**

Earth terminal of the oscilloscope

## 5. HOW TO PRODUCE THE BRIGHT LINE

Insert the plug of the power cord on the rear panel into the power supply wall socket and set the controls as follows.

<b>POWER</b>	OFF
<b>INTEN</b>	Counterclockwise to the full
<b>FOCUS</b>	Midrange
<b>AC-GND -DC</b>	GND
<b>◆ POSITION</b>	Midrange (the knob is in the depressed)
<b>V.MODE</b>	CH1
<b>TRIG</b>	AUTO
<b>TRIG SOURCE</b>	INT
<b>INT TRIG</b>	CH1
<b>TIME/DIV</b>	0.5ms/div
<b>◀▶ POSITION</b>	Midrange

Set all the levers of the switches to the upper side

After ending all the setting mentioned above, turn ON the POWER and, 15 second later, rotate the INTEN knob clockwise. Then the sweep bright line will appear .If the observation

is to be started immediately set the FOCUS control at a point where the bright line is sharpest if the instrument is not used with the power supply turned on rotate the INTENSITY counterclockwise to reduce the brightness and also blur the FOCUS.

### NOTE

For usual observation, leave the following non-calibrating function section set to "CAL"position.

<b>VARIABLE</b>	Rotate in the direction of arrow. In this case the VOLTS/DIV is calibrated to its indicating value.
<b>SWP VAR</b>	Leave the knob in depressed state. In this case the TIME/DIV is calibrated to its indicating value

Align the bright line with the horizontal scale line at the center of the screen by opetatingCH1 POSITION In some cases the bright line ,may be oblique to scale slightly by the effect of earth magnetism. In this case, bring the bright line until it lies on the horizontal scale line at the center of the screen by properly adjusting the semi-fixed variable resistor TRACE ROTATION on the front panel.

## GENERAL MEASUREMENT

### (1) In the case of observing a single waveform.

Use CH1 or CH2 when not observing the phase difference between two waveforms or when engaging in a operation other than X-Y operation. Make the following setting when using CH1

MODE Switch of Vertical deflection system	CH1
MODES witch of TRIG	AUTO
TRIG SOURCE	INT
INT TRIG	CH1

Under these setting almost all the repetitive signals of about 25 Hz or more applied to CH1 can be synchronized and observed by adjusting to TRIG LEVEL, since the MODE of horizontal axis is at AUTO position, the bright line appears even when no signal is present or when input the coupling switch is at GND position, This means that the measurement of DC voltage can be measured. The following switching is needed when observing low frequency signals about 25 Hz or less.

MODE of TRIG      NORM

Synchronization can be effected by operating LEVER knob under this setting.

When using only CH2, use the instrument after making the following settings.

MODE Switch of Vertical Axis	CH2
TRIG SOURCE	INT
INT TRIG	CH2

### (2) When observing two waveforms

Observation of two waveforms can be made easily by setting the MODE switch of vertical axis to ALT or CHOP. When observing two waveforms of high repetition frequencies set the MODE switch to ALT and, in the case of low frequencies, set it to CHOP.

When measuring the phase difference, measure after effecting synchronization with leading phase signal.



## 6. METHOD FOR CONNECTING SIGNALS

The first step of measurement is introduce the signal desired to measure the oscilloscope properly. Do it with utmost care.

### (1) When using a probe


Use the attached probe when measuring a high frequency wave with high accuracy.

It should be noted, however, that since the input signal is attenuated by this probe to 1/10 before it is input to the oscilloscope the use of the probe is disadvantageous for low signals, and that at the same time the measuring range is extended by that amount for high signals.

### <CAUTIONS>

- Do not apply a signal which exceed 400V(DC+peak AC at 1 kHz).
- Bring the grounding point of the earth lead wire of the probe close to the point to be measured when measuring a rapid rising signal or a high frequency signal. Long earth lead wire may cause waveform distortions such as ringing and overshoot.

### Connection of earth lead wire



(a) A good example

(b) A bad example

For better measurement it is required to use an earth attachment available at option.

Multiply the reading of VOLTS/DIV by 10

For example, if the VOLTS/DIV is 50mV/DIV, the read the wave form as


$$500\text{mV/div} \times 10 = 500\text{mV/div}$$

To avoid measurement error, put the probe in the following correction state and check it before measurement without fail.

Connect the tip of the probe to the output terminal CAL 0.5V of 1kHz calibration square wave voltage.

When this correction capacity value is at optimum the waveform takes the shape as shown in Fig(a) as follows.

If the waveform is as shown in Fig.(b) or Fig.(c), rotate the semifixed adjusting screw on the matching box of the probe by using a screwdriver until the optimum state is obtained.



**(2) At time of direct connection**

when connecting a signal directly to the oscilloscope not using the attached probe (10.1), pay attention to the following points in order to minimize the measurement error.

When performing observation using a bare lead wire, no trouble occurs if the circuit to be measured is of low impedance and high level.

However, note that, in most cases, measurement error may be caused by static stray coupling with other circuit and power line.

This measurement error cannot be ignored even in low frequency region.

In general, it is safe to avoid measuring with non-shielded connecting wire. When using a shielding wire connect one end of the shield to the earth terminal of the oscilloscope and the other end to the grounding of the circuit to be measured. It is desirable to use a coaxial cable with BNC type connector.

The following cautions must be observed when performing a wide band measurement. It is necessary to terminate with the characteristic impedance of the cable when measuring a rapid rising waveform or a high frequency wave.

Especially when using a long cable, the absence of a terminating resistor will necessarily lead to a measurement error derived from ringing phenomenon. Some measuring circuits require a terminating resistor equal to the characteristic impedance of the cable also on the measurement terminal side.

BNC type terminating resistor (50 Ω) is conveniently used for this purpose.

In order to perform measurement with the measuring circuit put in proper operating state it is sometimes necessary to terminate the cable with an impedance which corresponds to the circuit to be measured.

The stray capacity to the shield wire must be taken into account when performing measurement with a long shielded wire. Since the shield wire normally in use has

a capacity about 100 pF per meter, its effect on the circuit to be measured cannot be ignored Use a probe to minimize the effect on the circuit.

When the length of the shield wire used or when the length of the non-terminated cable reaches 1/4 wavelength or its multiples within the band of V-5060/V-552 type (1/4 wavelength is about 1.5 meter ( about 1.2 meter) when using a coaxial cable at 60MHz (50MHz), oscillation may be caused near 5mV/DIV range.

This is caused by the resonance between the externally connected high-Q inductance and the input capacity and can be avoided by reducing the Q.

Connect the cable or shield wire to the input connector by way of a serially connected 100 Ω to 1 k Ω resistor, or perform measurement at/ other VOLTS/DIV range.

### (3) When observing waveform with X-Y

Set the TIME/DIV switch to X-Y. Then the instrument works as an X-Y oscilloscope.

Each input is applied to the instrument as follows:

X-axis signal (horizontal axis signal)	CH1 INPUT
Y-axis signal (vertical axis signal)	CH2 INPUT

In this case leave the horizontal axis magnification switch (PULL-MAG x 10knob) at depressed position.

## 7. MEASURING PROCEDURE

The first things to do are as follows:

Bring the brightness and FOCUS at optimum positions for easy read out.

Display the waveform as large as possible to minimize the read error.

Check the capacity correction when using a probe.


(Refer to Paragraph (1) When using a probe of Section 6. Method for connecting signals for the method for correcting capacity.)

### (1) DC voltage measurement

Set input coupling to GND and decide the zero level properly.

Set VOLTS/DIV appropriately and set AC-GND-DC to DC. Since the bright line shifts here by the amount of DC voltage, the DC voltage of the signal can be obtained by multiplying the shift width by the indicated value of VOLTS/DIV. When VOLTS/DIV is 50 mV/DIV, then  $50 \text{ mV/div} \times 4.2 = 210 \text{ mV}$ / However, if the probe (10:1) is in use, the true value of the signal becomes 10 times the value, or  $50 \text{ mV/div} \times 4.2 \times 10 = 2.1 \text{ V}$






### (2) AC voltage measurement

The same as paragraph 7 (1), “DC voltage measurement”, but here there is no need of matching the zero level with the scale line. Move the zero level at will to a position easy to observe.

In the drawing as follows, VOLTS/DIV is 1V/DIV, 1V/div x 5 = 5 V<sub>p-p</sub> (50 V<sub>p-p</sub> at time using the probe (10:1). When magnifying and observing a small-amplitude signal, superimposing on a high DC voltage, set input coupling of AC. The AC voltage is cut off and AC voltage can be observed by increasing sensitivity.



### (3) Measurement of frequency and period

This will be explained taking the drawing as follows as an example.

One period covers the time A and time B, which are separated from each other by 2.0div on the screen.


When the sweep time is 1 ms/DIV, the period is given by

$$1 \text{ ms/div} \times 2.0 = 2.0 \text{ ms} \\ = 2.0 \times 10^{-3} \text{ s}$$

Accordingly, the frequency is


$$1/(2.0 \times 10^{-3}) = 500 \text{ Hz}$$

(However, when the knob MAG × 10 is at pulled out position, TIME/DIV must be converted to 1/10 since the sweep is magnified.)



**(4) Measurement of time difference**

Triggering signal source "SOURCE" is selected as offering reference signal when measuring the time difference between two signals. Assume that pulse trains as shown in (a). Then (b) shows the case when CH1 is taken as the triggering signal source and (c) the case where CH2 is taken.




This means that CH1 is used as the triggering signal when investigating the length of time by which the signal of CH2 is delayed from the signal of CH1. CH2 is used in the reversed case. In other words, the signal leading in phase is selected as the triggering signal source.


If this process is reversed, the portion to be measured may sometimes not appear on the screen. Thereafter, equalize the amplitudes of the two signals appearing on the screen or superimpose one on another.

Read the time difference by the interval between 50% amplitude points of the two signals.

Sometimes the superimposing method is more convenient from the point of view of procedure.



(a) Equal amplitude measuring method



(b) Superposition measuring method

**<CAUTIONS>**

Since the pulsed wave contains many high-frequency wave components (higher harmonics) depending on its width or

Period, pay the same attention as give to high frequency signals when handling it. Accordingly ,use a probe or coaxial cable and shorten the earth lead wire as possible.

**(5)Measurement of rise (fall)time**

To measure the rise time pay attention not only to the abovementioned items but also to measurement error. The following relationship exists between the rise time  $Tr_x$  of the waveform to be measured, the rise time  $Tr_s$  of oscilloscope, and the rise time  $Tro$  displayed on the screen.

$$Tro = \sqrt{Tr_x^2 + Tr_s^2}$$

When the rise of the pulse going to be measured is sufficiently longer than the rise time of the oscilloscope (7ns in our case).the effect of the rise time of the oscilloscope on the measurement can be neglected ,However ,if both are close to each other, measurement error may be caused.

The true rise time is given by

$$Tro = \sqrt{Tro^2 + Tr_s^2}$$

Moreover, in general, in a circuit free from waveform distortion such as overshoot and sag, the following relationship is established between frequency band and rise time.

$$f_c \times t_r = 0.35$$

Where,  $f_c$  : Frequency band(Hz)  
 $t_r$  :Rise time (S)


The rise time and fall time are determined by the time elapsed between the 10% to90% values of pulse width This oscilloscope is provided with graduations for 0%, 10%, 90%, and 100% on the screen, which facilitate measurement.

**(6) Synchronization of complexed waveform**

In the case shown in the fig. (a) below where waveforms greatly different in amplitude alternate. the waveform is doubled if the trigger level is not set properly .In the case where the trigger level is selected as Y line two waveforms, one starting with A and advancing to B, C, D, E, F, . . . , And the other starting with E and advancing to F, G, H, I . . . , Will appear alternately, on the screen. They will be doubled as shown in Fig(b), for which no synchronization can be taken.

In such a case, rotate LEVEL clockwise until the trigger level comes to Y line ,Then the waveform on the screen becomes the one is shown in Fig. (c)above which start with Band advances to C, E, F, . . . and which allows synchronization





**(7) synchronization of observing two waveforms**

- ① When two signals of CH1 and CH2 have same frequencies or the frequencies of an integral number or the frequencies in a relation of a specific time difference, the INT TRIG switch selects either CH1 or CH2 as a reference signal. CH1 position selects CH1 signal as a reference, and CH2 position selects CH2 signal.
- ② For an observation of signals for different frequencies set the INT TRIG switch to the VERT MODE. The sync signal switches at each alternation of channels, and the waveform of each channel is stably triggered.

**SELECTION OF A TRIGGER SOURCE ON THE VERT MODE**

- A. Trigger signal is obtained the following steps
- 1) set the SOURCE switch (31) to INT.
  - 2) set the INT TRIG switch (32) to VERT MODE
  - 3) select the MODE switch

**Table 1.**

**Relation of trigger signal sources and switches**

SOURCE		INT			LINE	EXT
INTTRIG		CH1	CH2	VERT MODE	Line	External
V	CH1	CH1	CH2	CH1		
	CH2	CH1	CH2	CH2		
M O D E	ALT	CH1	CH2	CH1 CH 2(ALT)		
	CHOP	CH1	CH2	ADD		
	ADD	CH1	CH2	ADD		

When the SOURCE switch to INT, TRIG switch to VERT MODE, and MODE switch to ALT, the input signals applied to CH1 and CH2 become trigger source alternatively at each sweep. Consequently, even for an observation of two waveforms of different frequencies, the waveform of the each channel is stably triggered.

In this case ,the signal should be applied to both CH1 and CH2 and the two signals have the same level portion in excess of the rated amplitude each other. There should be a common portion of levels available that is above the rated amplitude of CH1 and CH2.

when a sinewave is applied to CH1, and a square wave is applied to CH2, "A"s in Fig. 1 are the levels possible for synchronization.




Fig.1

In order to expand the synchronization range , AC coupling is applied to the Ch2side.

When either the Ch1 or CH2 input signal is smaller as shwonin Fig.2, adjust the VOLTS/DIV switches (13) and (14) to obtain sufficient amplitudes.

The VERT MODE triggering requires 1.5 div mire than the amplitude required for an observation of ch1 or CH2.




Fig.2

The CERT MODE triggering is not possible when the signal is applied to only one channel as illustrated on Fig.3.





Fig3

Caution: Do not use the INT TRIG to the VERT MODE when PULL×5 GAIN ⑮ and/or ⑯ are in the pulled out position(×5 GAIN mode)

**ALTERNATE TRIGGER**


Jittering wave as shown below may appear on the screen when a gently-sloping signal is displayed by approximate 10 cycles or less .with the VERT MODE for the INT TRIG switch and the ALR position for the MODE select witch. For detailed and clear observation of each signal, set the MODE select switch Ch1 or Ch2






**(8)How to use TV exclusive synchronization**

① **On the image waveform of TV**

In the work concerned with TV, complexed signals containing video signal, blanking pedestal signal, and synchronizing signal are often measured. However, since the waveform is complexed, a special circuit is needed to effect a stable synchronization with vertical waveform.




② **Difference in the circuits**

	Exclusive circuit for conventional oscillograph		Exclusive circuit for this instrument (principle drawing)
	General circuit	simple synchronizing circuit	TV exclusive synchronizing separator circuit
Circuits	<p>Video signal</p> <p>To trigger circuit</p> 	<p>To trigger circuit</p> 	
	<p>Hard to synchronize, because video signal applied directly as trigger signal.</p>	<p>Synchronization is more easily effected than in the circuit shown at left, because the signal is integrated to remove high frequency components.</p>	<p>Stable synchronization is obtained since SYNC pulse is picked up, amplified, and then integrated to remove high frequency components.</p>




③ Operation

To observe vertical signal



**TRIG** MODE: TV-V


To observe horizontal signal



**TRIG** MODE: TV-H

(NOTE) This oscilloscope synchronizes with only (-) synchronizing signal.

(REFERENCE)



(a) Example of (-) synchronizing signal

(b) Example of (+) synchronizing signal

(9) DC OFFSET

The oscilloscope provides the Dc offset voltage display or  $\pm 1$  to  $\pm 100V$  according to the range  
An output terminal for voltage reading  
( Except :  $\times 5GAIN$ , out of CAL)




Fig.7-1 Diagram of DC OFFSET

see Fig ,7-1 for the function of the DD OFFSET  
There is following relation among the differential amplifier output voltage  $e_o$ , the input voltages  $e_i$  and  $E_2$

$$e_o = A(e_i - E_2)$$

$$e_i = E_{DC} + e_{AC}$$

(where  $E_{DC}$  is a DC input and  $e_{AC}$  is an AC input)

set the controls so that  $E_2 = E_{DC}$  is attained. Then  $e_o = A e_{AC}$  is obtained.

The DC component can be removed for an observation

**OFFSET voltage ranges**

VOLTS/DIV	DC OFFSET voltage
5mV/div-50mV/div	More than $\pm 1V(x1)$
0.1V/div-0.5V/div	more than $\pm 10V(x10)$
1V/div-5V/div	more than $\pm 100V(x100)$

When measured with a DMM connection, multiply the DMM reading by the multiplier written above in indentation

Read next paragraph for the detailed explanation of measurement with a DMM connection.

**(10) Measurement by the DC OFFSET function**

In order to readout the voltage level digitally, connect a DMM ( digital multimeter ) to the DC OFFSET output terminal and set the oscilloscope to the DC OFFSET mode. see Fig.7-2

1)Measuring DC component

Align level ② with the center graticule and read the DMM digital value (+2V should be displayed.)




Fig.7-2 Transistor amplifier

**2)Measuring AC component**

When the above is performed with an input sensitivity of 50mV then 4 div of amplitude must be present on the oscilloscope screen.

The AC component is observable on the oscilloscope screen where as the DC component is measurable on a DMM, and there is no need for any complicated switching as such needed for conventional oscilloscopes.

Moreover the DC OFFSET function provides readings of peak to peak value(p-p)of  $e_o$  on DMM.

Align level ② with the center graticule line on the screen ,read the DMM value and name it V(a), then align level ③ with the graticule line and readout V (c).The p-p



the difference between V(a) and V(c), and the value can be read digitally on the DMM.

As explained above, the DC OFFSET function with DC OFFSET output terminal offers an improved operational convenience and a highly accurate measurement in detailed waveform portions.

## 8. ADJUSTMENTS

The ATT balance of the vertical axis can be made easily.

- ① Set the input coupling switches of CH1 and CH2 to GND and set the TRIG MODE to AUTO. Then position the bright line to the center.
- ② Turn the VOLTS/DIV switch to 5mV-10mV and adjust so that the bright line does not move.

( DC BAL ②④ ②⑤ )

## 9. MAINTENANCE

- 1) Since semiconductors ,precision components, etc.are employed in this oscilloscope, use at most care for operation and storage.
- 2) Clean the scale with soft tissue periodically
- 3) Side panel can be removed with screws
- 4) Store this oscilloscope in the ambient temperature from -10°C to +50°C.

## 10. SPECIFICATIONS

CRT

### Type

Large6"screen with internal graticule.  
Approximate 12kv acceleration potential.

### Phosphor

P31 standard

### Graticule

8×10div(div=10mm)  
Internal graticule

### Focussing

possible (with automatic focus correction circuit)

Trace rotation	present
Brightness adjustment	possible
Scale illumination	variable

## Z-AXIS INPUT(INTENSITY MODULATION)

DC-coupled ,positive-going signal decreases intensity:  
5Vp-p signal causes noticeable modulation at normal

Intensity: DC to 2MHz  
Input impedance 33kohm(typ.)  
Maximum input voltage 30v(DC+peak AC)

**VERTICAL DEFLECTION SYSTEM(2 identical channels)**

**Bandwidth and rise time**

DC to at least 60MHz (50MHz) and rise time 7ns  
[ 17.5 ns ] or less. DC to at least 7 MHz and rise time  
50ns or less .at magnifier extends, The AC coupled  
lower -3dB point is 10Hz or less.

**Deflection factor**

5mV/div to 5V /div in 10 calibrated steps in a 1-2-5  
sequence. Uncalibrated continuous control extends de-  
flection factor to at least 12.5 Volts per division in the  
5 Volts/div position x5 magnifier increases sensitivity of  
each deflection factor setting to 1mv/div

**Accuracy**

±3%  
Additional error for magnifier ±2%

**Display modes**

CH1,CH2(normal or invert), Alternate, chopped  
(approximate 250kHz), Added

**Input Impeuance**

Approximately 1 M $\Omega$  in parallel with 25 pF

**Maximum input voltage**

300V(DC+pake AC)or 500Vp-pACat 1 kHz or less

**Input coupling**

AC, GND, DC

**DC OFFSET**

**DC OFFSET VOLT OUT**

**HORIZONTAL DEFLECTION SUSTEM**

**Time base**

0.2  $\mu$  s/div to 0.2s/div in 19 calibrated steps in a-1-2-5  
sequence, Uncalibrated continuous control extends de-  
flection factor to at lease 0.5 seconds per division in  
the 0.2sec/div position x10 mag extends maximum  
sweep rate to 20 ns/div [ 100ns/div ] .

**Accutacy**

±3%  
Additional error for magnifier ±2%



### TRIGGERING SYSTEM

#### Trigger modes

Automatic Normal, TV(TV-H or TV-V)

#### Trigger source

Internal (CH1,CH2 v-MODE),Line,External

#### Trigger slope

+,-

#### TV sync polarity

TV(-)

TV-Vsensitivity :SYNC section less 1 div ir 1V

AUTO low band: Approximately 25Hz

#### Trigger coupling

AC : 20Hz to full band width

#### External trigger input impedance

Approximately 1M $\Omega$  In parallel with 30pF

#### Maximum input voltage

300V(DC+AC peak)

ALT MAG present

### X-Y OPERATION (CH1; Horiz,CH2; vert,

#### Deflection factor

same as Vertical deflection

#### X-bandwidth

DC to at least 500kHz

#### Phase error

3 $^{\circ}$  or less from DC to 50kHz

### CALIBRATOR

An approximate 1kHz frequency 0.5V (  $\pm$ 3%) square wave.

**SIGNAL OUTPUT**

**CH1 VERT SIGNAL OUTPUT**

Output voltage is at least 20mV/div into a 50 ohm load.  
Bandwidth is 50Hz to at least 5MHz

**POWER SUPPLY**

VOLTAGE(50Hz)	FUSE
220V(198-242V)	0.5A

Power supply frequency :50Hz  
Power consumption: Approx. 35W [30W]  
Max.40W at 120V 60Hz



**ENVIRONMENT**

Limit of operation temperature	0-+40°C
Limit of operation humidity	35-85%
Rated range of use temperature	+10-+35o°C
Rated range of use humidity	45-85%
storage and transport temperature	-10°C-+50°C

**DIMENSION AND WEIGHT**

Approx.310(w)×130(H)×370(D)mm  
(12.4(W)×5.2(H)×14.8(D)inch)  
Approx.6.5kg (14.61bs) [6kg(13.51bs)]

**11. EXTERNAL VIEW**



V-552 V-5060 Unit:mm



MUMBAI

**TEST CERTIFICATE**

**DIGITAL ANALOG STORAGE OSCILLOSCOPE**

This Test Certificate warrants that the product has been inspected and tested in accordance with the published specifications.

The instrument has been calibrated by using equipment which has already been calibrated to standards traceable to national standards.

MODEL NO. \_\_\_\_\_

SERIAL NO. \_\_\_\_\_

DATE: \_\_\_\_\_

ISO 9001 REGISTERED



## **WARRANTY**

Each "KUSAM-MECO" product is warranted to be free from defects in material and workmanship under normal use & service. The warranty period is one year (12 months) and begins from the date of despatch of goods. In case any defect occurs in functioning of the instrument, under proper use, within the guarantee period, the same will be rectified by us free of charges, provided the to and fro freight charges are borne by you.

This warranty extends only to the original buyer or end-user customer of a "KUSAM-MECO" authorized dealer.

This warranty does not apply for damaged Ic's, burnt PCB's, fuses, disposable batteries, carrying case, test leads, or to any product which in "KUSAM-MECO's" opinion, has been misused, altered, neglected, contaminated or damaged by accident or abnormal conditions of operation or handling.

"KUSAM-MECO" authorized dealer shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of "KUSAM-MECO".

"KUSAM-MECO's" warranty obligation is limited, at option, free of charge repair, or replacement of a defective product which is returned to a "KUSAM-MECO" authorized service center within the warranty period.

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. "KUSAM-MECO" SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE WHATSOEVER.

All transaction are subject to Mumbai Jurisdiction.



17, Bharat Industrial Estate, T. J. Road, Sewree (W),  
Mumbai-400015. INDIA

**Sales Direct:** 24156638 **Tel.:**(022)2412 4540, 2418 1649 **Fax:**2414 9659

**E-mail :** kusam\_meco@vsnl.net,

**Website :** www.kusamelectrical.com, www.kusam-meco.co.in